



**Fitting Instructions:**      **HAV01H**

**Vehicle:**                      Haval H6 Wagon 10-2016 On

**Towing Capacity**        2000Kgs / 200Kgs (Towball Load)

**Fitting Kit:**                      4 – 12 x 40mm **Medium thread Nuts**, star and flat washers

2 – 11/4" x 3/8" Bolts on wire, (No washers) nuts, star & flat washers

2 – Dee shackles

2 – Towbar rating labels

**\*\*\*ECM Required\*\*\***

1.	<b>Bumper Cut.</b> Locate centre of bumper and cut 45mm either side. Cut 75mm up from edge of bumper bar base and discard cut out.
2.	Feed 1¼ x 3/8 wire to bolts into chassis via forward most holes. (1 either side) Align with rear most hole. (1 either side)
3.	Mount Tow hitch via 12mm studs, fit nuts and complete with flat and star washers.
4.	Fit 3/8 nuts to wires, complete with flat and star washers.
5.	Tighten all bolts.
6.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.