



Fitting Instructions: **HAV02H**

Vehicle: Haval H9 Wagon 10-2015 On

Towing Capacity 2500Kgs / 250Kgs (Towball Load)

Fitting Kit: 4 – 12 x 40 Bolts on wire, (No washers) with Flange nuts

2 – Dee shackles

2 – Towbar Rating Labels

*****ECM Required*****

1.	Bumper Cut required prior to installation Locate centre of bumper and mark 98mm either side of centre. Mark 70mm up from edge of base of bumper. Cut out this section and discard.
2.	Remove centre bumper bar cover plate.
3.	Mount Tow hitch to rear cross member, align with original holes that contain 12mm internal threads. (4 in total)
4.	Fit 12mm bolts on wire into rear chassis cross member and through existing hole which align with tow hitch. Fit flange nuts & tighten
5.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.