

Fitting Instructions



SKU

PRODUCT

T2F512

**TAG Standard Duty Towbar
to suit Ford Focus
(05/2005 - 2016)**



Scan for latest
version of these
instructions

SPECIFICATIONS

- Towbar Class: Standard Duty
- Towing Capacity: 900kg

IN THIS GUIDE

- Fitment Instructions
- Torque Settings
- Warranty Info

Towbar Fitting Instructions



Step-By-Step Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. REMOVE ALL BOLTS FROM TOWBAR TAKING NOTE OF LOCATIONS.
 - 1.1. REMOVAL OF BUMPER / REMOVE TORQUE HEAD SCREWS FROM EACH WHEEL ARCH AND 10MM HEAD LOCK TIGHT NUT FROM TOP INSIDE FACE IN EACH WHEEL ARCH.
 - 1.2. LIFT TAIL GATE TO REMOVE TORQUE HEAD SCREWS FROM TOP OF BUMPER; REMOVE 2 MORE FROM UNDER SIDE REAR OF BUMPER, REMOVE BUMPER PULLING OUT AT SIDES FIRST THEN REARWARDS.
2. REMOVE IMPACT BEAM FROM VEHICLE AND DISCARD/REMOVE STICKERS FROM SIDE OF SUBFRAME COVERING EXISTING FACTORY HOLES.
3. FIT TOWBAR ONTO VEHICLE AND SECURE WITH 4 X M10 BOLTS, PLATES AND WASHERS SUPPLIED.
 - 3.1. TIGHTEN ALL BOLTS TO SPECIFIED RATINGS.

Towbar Fitting Instructions



4. REFIT BUMPER ONTO VEHICLE.

4.1. FIT BALL MOUNT ONTO VEHICLE USING 2 X M16 BOLTS AND WASHERS SUPPLIED AND TIGHTEN.

4.2. ATTACH DOOR STICKERS TO DRIVERS SIDE DOOR PILLAR.

NOTE: 08/11 onwards models require an ecu to be installed.

Torque table for bolt tightening

Metric GRADE 8.8	UNC GRADE 8
M6 – 12.5 Nm	3/8 – 50 Nm
M8 – 30 Nm	1/2 - 125 Nm
M10 – 60 Nm	5/8 – 245 Nm
M12 – 103 Nm	
M14 – 167 Nm	
M16 – 270 Nm	

TAG Warranty Statement

SWD warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us direct by phone on 1300 669122 or visit www.swd.com.au