Fitting Instructions



SKU

PRODUCT

T2M480

TAG Standard Duty Towbar to suit Mazda 3 (04/2004 - 09/2009)





Scan for latest version of these instructions

SPECIFICATIONS

- Towbar Class: Standard Duty
- · Towing Capacity: 750kg

IN THIS GUIDE

- · Fitment Instructions
- Torque Settings
- · Warranty Info

Towbar Fitting Instructions



Step-By-Step Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

- 1. Remove bumper bar
 - 1.1. Remove screws and clips from wheel arch.
 - 1.2. Remove two plastic scrivets from bottom of bumper.
 - 1.3. Flex bumper sideways to unclip from body.
 - 1.4. Remove boot trim.
 - 1.5. Remove tail lights.
 - 1.6. Remove one screw and one scrivet from behind tail lights.
- 2. Remove impact beam and discard.
- 3. Release exhaust mount from chassis rail.
- 4. Fit tow bar to rear of car by sliding forward arms down chassis rail.
- 5. Fit 2 x M12 bolts and washers through bottom of chassis rail into welded nuts on forward arms of tow bar.

Call 1300 326 134 Version 23.01.2022

Towbar Fitting Instructions



- 6. Fit 8 x 10mm wiz nuts to stude at rear of car.
- 7. Tighten all bolts to torque listing.
- 8. Refit exhaust. 9) Refit bumper.
- 9. Refit boot trim.
- 10. Fit tongue with bolts supplied.
- 11. Fit door sticker supplied to door.

Torque table for bolt tightening

Metric GRADE 8.8
M6 – 9.5 Nm
M8 – 21.7 Nm
M10 – 43.4 Nm
M12 – 77.3 Nm
M16 – 189.8 Nm

TAG Warranty Statement

SWD warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us direct by phone on 1300 669122 or visit www.swd.com.au

Call 1300 326 134 Version 23.01.2022