

Fitting Instructions



SKU

PRODUCT

T4D469

**TAG Heavy Duty Towbar to
suit Nissan Pathfinder
(07/2005 - 2013)**



Scan for latest
version of these
instructions

SPECIFICATIONS

- Towbar Class: Heavy Duty
- Towing Capacity: 3000kg

IN THIS GUIDE

- Fitment Instructions
- Torque Settings
- Warranty Info

Step-By-Step Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. REMOVE ALL BOLTS FROM TOWBAR TAKING NOTE OF LOCATIONS AND ASSEMBLY.
 - 1.1. REMOVE SPARE WHEEL FROM VEHICLE.
 - 1.2. REMOVE EXHAUST FROM REAR HANGER.
 - 1.3. REMOVE BOLTS HOLDING IMPACT BEAM ON THE INSIDE OF CHASSIS BEHIND BUMPER AND REMOVE.
2. **NOTE: AS BUMPERS MAY VARY IN FITMENT, TOWBAR WILL HAVE TO BE TRIAL FITTED FOR POSSIBLE CUT OUT OF BUMPER TO BE DONE. 100MM WIDE X 25MM DEEP FROM BOTTOM CENTRE.**
 - 2.1. FIT TOWBAR TO VEHICLE SECURING WITH BOLTS AND WASHERS SUPPLIED INTO EXISTING CAPTIVE NUTS ON THE INSIDE OF CHASSIS.

Towbar Fitting Instructions



2.2. USING HOLES IN UNDERSIDE TABS OF TOWBAR AS A GUIDE, DRILL HOLES IN BOTTOM OF CHASSIS AND SECURE WITH TAPPED PLATES ON WIRE INSERTED INTO CHASSIS AND BOLTED FROM UNDERNEATH WITH ½ INCH BOLTS AND WASHERS SUPPLIED.

3. TIGHTEN ALL BOLTS TO SPECIFIED RATINGS.

3.1. REFIT EXHAUST AND SPARE WHEEL BACK ONTO VEHICLE.

3.2. FIT BALL MOUNT USING PIN AND CLIP SUPPLIED.

ATTACH RATINGS STICKER TO DRIVERS SIDE DOOR PILLAR

Torque table for bolt tightening

Metric GRADE 8.8	UNC GRADE 8
M6 – 12.5 Nm	3/8 – 50 Nm
M8 – 30 Nm	1/2 – 125 Nm
M10 – 60 Nm	5/8 – 245 Nm
M12 – 103 Nm	
M14 – 167 Nm	
M16 – 270 Nm	

TAG Warranty Statement

SWD warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us direct by phone on 1300 669122 or visit www.swd.com.au