

Installation Tips for Wall Mount Sinks

To determine the most suitable installation type you first need to determine the type of wall the sink will be installed on. This is how we recommend installing your new sink based on your wall type.

<u>Drywall Alone</u>: Use Toggle Bolts.



Wood Backed Drywall: Use 3/8" x 3" long screws with washers.





Brick / Concrete: Use ribbed plastic anchors and 3/8" x 3" long screws with washers.



The sink will then rest on the screws / bolts. Using the u-shaped openings in the back of the sink.

