

PANDUIT® NET-ACCESS S-Type and N-Type Cabinets (Rear Split Doors)

INSTRUCTIONS CM617

© Panduit Corp. 2013

Rear Split Doors - Installation

- Align [4] Locating Pins of each Hinge Bracket with matching hole pattern of cabinet frame
- Secure [4] Hinge Brackets to cabinet frame with [1] M6 x 12mm Torx Screw per bracket (use T30 Torx bit)
- Open Door(s) to approximately 90°
- Lift Door(s) up and insert hinge pins of door(s) into hinge brackets
- REVERSE STEPS to remove split doors

