



## ART. W098

**Cover for installing the shower head in the ceiling of a Hammam**

- waterproof
- for art. C031 - C032 - K021 - K022 - K001 - K002 - K061 - K062
- to be installed before the false ceiling is created
- installation instructions on Acqua Zone and Acquafit technical pages

**Date**

---

**Project/Comments:**

---

---

---

---

---

---

---

---

## Finishing:



91 00 W098