



## ART. W098

### Cover for installing the shower head in the ceiling of a Hammam

- for art. C031 - C032 - K021 - K022 - K001 - K002 - K061 - K062 - V561 - V562
- waterproof
- to be installed before the false ceiling is created
- installation instructions on Acqua Zone and Acquafit technical pages

## Date

---

## Project/Comments:

---

---

---

---

---

---

---

---

## Finish:



91 00 W098