



ART. W098

Cover for installing the shower head in the ceiling of a Hammam

- waterproof
- for art. C031 - C032 - K021 - K022 - K001 - K002 - K061 - K062 - V561 - V562
- to be installed before the false ceiling is created
- installation instructions on Acqua Zone and Acquafit technical pages

Date

Project/Comments:

Finish:



91 00 W098