



ART. W098

用于湿蒸房天花安装的顶洒

- 见款式. C031 - C032 - K021 - K022 - K001 - K002 - K061 - K062 - V561 - V562
- 防水的
- 在做假天花板之前安装
- Acqua Zone和Acquafit技术信息页面上的安装说明

日期

项目/备注

漆面

91 00 W098