

**Terminal 1**

design Jean-Marie Massaud
anno/year 2008

Istruzioni di montaggio: piedini e puntali

Assembly instructions: feet and glides

Montageanleitung: Füße und Fußstützen

Instructions de montage: pieds et embouts

Instrucciones para el montaje: patas y puntales

Инструкции по монтажу: ножки и основания

IMPORTANTE
CONSERVARE PER
FUTURE REFERENZE:
leggere attentamente!

IMPORTANT - KEEP
FOR FUTURE
REFERENCE: read
carefully!

WICHTIG – UNBEDINGT
AUFBEWAHREN
UND AUFMERKSAM
DURCHLESEN!

IMPORTANT A
CONSERVER POUR
LES RÉFÉRENCES
FUTURES:
lire attentivement !

IMPORTANTE
CONSERVAR
PARA FUTURAS
REFERENCIAS: leer
atentamente!

ВНИМАНИЕ!
СОХРАНИТЬ ДЛЯ
ИСПОЛЬЗОВАНИЯ
В БУДУЩЕМ:
внимательно
прочитать!

Italiano	English	Deutsch	Français	Español	Русский
1. Svitare le due piastre filettate manualmente o utilizzando la chiave a forchetta n. 24.	1. Unscrew the two threaded plates manually or with a n. 24 fork wrench.	1. Die beiden Gewindeplatten manuell aufschrauben; dabei den Steckschlüssel Nr. 24 verwenden.	1. Dévisser les deux plaques filetées manuellement ou en utilisant la clé plate de 24.	1. Desenroscar las dos placas manualmente o utilizando la llave abierta n. 24.	1. Отвинтить вручную или с помощью рожкового гаечного ключа № 24 две навинченные пластинки.
					

2. Avvitare i due piedini nella sede filettata della struttura, serrare a fondo utilizzando la chiave esagonale n. 6. 3. Applicare il puntale plastico agendo con pressione.	2. Screw the two feet into the threaded holes in the frame, tighten fully with a n. 6 Allen wrench. 3. Use pressure to apply the plastic tip.	2. Die beiden Füße an den Gewindesitz der Struktur anschrauben, bis zum Anschlag festziehen; dabei den Sechskantschlüssel Nr. 6 verwenden. 3. Die Plastikfußstütze andrücken.	2. Visser les deux pieds dans le logement fileté de la structure, serrer au maximum en utilisant la clé hexagonale 6. 3. Appliquer l'embout en plastique en agissant avec pression.	2. Enroscar las dos patas en el alojamiento roscado de la estructura, apretar a fondo utilizando la llave hexagonal n. 6. 3. Aplicar el puntal de plástico mediante una ligera presión.	2. Ввинтить ножки в резьбовые гнезда в структуре, затянуть с помощью шестигранного ключа № 6. 3. Вставить пластмассовый наконечник, надавив на него.
					