## Wall Studs

- Designed for pre-fab..
- Outlet boxes mount to the CROC-LOK with single screw.
- CROC-LOK box assemblies can be attached before or after the telescoping bar is mounted in the stud wall.
- The tool-less design enables CROC-LOK assemblies to be field installed in less than 4 seconds. Simply squeeze, secure and walk away.
- See Ruff-IN<sup>™</sup> brochure for pre-fab box assemblies.



## CROC-LOK™ Box Mounting Bracket



UPC/Part Number	Catalog Number	Stud Spacing	Description	Box Qty.
782051 51291	BB2CL	N/A	Croc-Lok only	50
782051 51292	BB216TCL	11"-16"	BB216T with Croc-Lok	20
782051 51293	BB224TCL	15"-24"	BB224T with Croc-Lok	20
		U.S. Patent # 8,403,277		

Note:

Secures to Cooper B-Line BB2-16T and BB2-24T telescoping brackets only. For a standard  $2^{1/8}$ " deep box, the stud depth must be  $3^{1/2}$ " or greater. For a shallow  $1^{1/2}$ " deep box, the stud depth must be  $2^{1/2}$ " or greater.



Note: BWHS-9 & BWHS-9D can be used with all fasteners requiring attachment with sheet metal screws, except on BB2-16, BB2-16D, BB2-24 & BB2-24D which only BWHS-9 can be used.

Read safety/installation instruction sheets in packages before use. These products are designed for positioning only. No load rating.

27

