NATIVE T R A I L S

## 1 2 3 4 5 6

## INSTALLATION INSTRUCTIONS 2" JR. BASKET STRAINER, DR220

- 1. Apply a small bead of 100% Silicone (non-water based) to the underside of strainer body flange (3).
- 2. Place stariner body (3) into sink.
- 3. Place rubber seal (4) on top of drain cup (5).

4. Place tightening screw (2) into center of strainer body (3) and secure .

- Lubricate (1) with liquid soap. Place strainer basket (1) into strainer body (3).
- Attach drainpipe (not shown) to drain cup (5) using nut (6).

Remove all excess silicone around the drain after the drain has been installed

W W W . N A T I V E T R A I L S . N E T