

# Rough in ready. Finish with style.

Rough it in now, finish it later. +osb™ Testable Bath Waste Rough-ins let you install and test early in the build - keeping your trims protected until project completion.

Choose from ABS, PVC, or Brass Rough-ins, available in various configurations and kit types, and pair them with stylish Trims offered in multiple models and finishes.

**and done.**



Visit our YouTube Channel to watch the video



Visit our website to see the assortment

**+osb™** and done.

osb.ca (Canada)  
osbplumbing.com (USA)

TESTWO-PB1025FR-EN

# Installez maintenant, terminez plus tard.

Les trop-pleins de baignoire testables pour l'étape de préinstallation +osb™ vous permettent d'installer et de tester dès les premières étapes de la construction - tout en gardant les garnitures protégées jusqu'à la fin du projet.

Choisissez parmi des kits de trop-pleins en ABS, PVC ou laiton, offerts dans diverses configurations et types de kits, puis agencez-les à des kits de finition élégants offerts en plusieurs modèles et finis.

**et c'est réglé.**



Visitez notre chaîne  
YouTube pour  
regarder la vidéo



Visitez notre site web  
pour découvrir notre  
assortiment

**+osb™**

osb.ca

TESTWO-PB1025FR-EN