


Side Discharge Drains: Because Jackhammers shouldn't be part of the job!

Say goodbye to breaking concrete with our Side Discharge Shower Drains.

Perfect for converting tubs to showers in concrete floor applications, this clever design connects to existing plumbing without the need to dig into the slab. It's the smart, clean, and efficient way to streamline your shower installs.

and done.



Visit our website
to see the
assortment

+osb™ and
done.

osb.ca (Canada)
osbplumbing.com (USA)

+osb SDDPB-0625




Moins de béton à casser, plus de temps pour installer.

Parce que les marteaux-piqueurs ne devraient pas faire partie du chantier! Fini de casser du béton grâce à nos drains de douche à sortie latérale.

Parfaits pour transformer une baignoire en douche sur plancher de béton, ces drains ingénieux se raccordent à la plomberie existante sans devoir creuser dans la dalle. Une solution intelligente, propre et efficace pour simplifier vos installations de douche.

et c'est réglé.



Visitez notre site web
pour découvrir notre
assortiment

+osb™



osb.ca