

Model:

# 360.210

## Collapsible Water Barrier



**READ ALL INSTRUCTIONS CAREFULLY AND INSPECT PRODUCT FOR DAMAGE BEFORE STARTING YOUR INSTALLATION.**

### INCLUDED IN PACKAGE:

One (1) 67" Long Collapsible Water Barrier  
Instructions on package

### TOOLS AND MATERIALS REQUIRED FOR INSTALLATION:

Utility knife  
Tape measure  
100% Silicone sealer (white or clear)  
Masking tape  
Rubbing alcohol  
Clean rags



### SURFACE PREPARATION:

Clean threshold and wipe with rubbing alcohol.

### INSTALLATION

**NOTE:** The Collapsible Water Barrier (Strip) is 67" long and requires trimming to install.

#### STEP 1:

Start at one end when preparing the cut to length.

#### STEP 2:

Be sure to account for the angled side walls of the shower floor.

#### STEP 3:

Use masking tape to hold down the Strip while measuring and making the cut. **DO NOT REMOVE FILM FROM ADHESIVE TAPE AT THIS TIME!**

#### STEP 4:

Use a pencil to mark the location of the strip on the threshold.

#### STEP 5:

Remove 6" of the protective film from sealing tape to start the installation.

#### STEP 6:

Apply sealer/adhesive to the cut end of the Strip.

#### STEP 7:

Using the pencil mark, align the Strip on the threshold. Press firmly to adhere the Strip. Stretch opposite end to wall and recheck alignment.

#### STEP 8:

Peel all but the last 12" off of the protective tape, stretch and place the Strip using the alignment marks.

#### STEP 9:

Double check the overall length and re-cut if necessary. Remove remainder of the film and apply sealer to the end and press into place.

#### STEP 10:

Allow sealer to dry thoroughly before applying any additional caulk. Use masking tape to temporarily hold ends of Strip in place until sealant/adhesive cures. **OPTIONAL:** The outer edges may be caulked if desired. Wipe off excess caulk and let cure following manufacturers specifications.

### CARE & CLEANING

The surface of your Collapsible Water Barrier may be cleaned with a mild soap solution in warm water using a soft cloth. When using a cleaner product, carefully read the label to ensure that the cleaner is safe for use on the material. Stubborn stains can be cleaned using "Soft Scrub®" by Clorox®, "Tub & Tile Cleaner®" by Lysol® or a powdered detergent such as "Spic-n-Span®."

Do not allow cleaners to sit or soak on the surface. Wipe surface clean and rinse completely with water immediately after cleaner application. Rinse and dry any overspray on nearby surfaces.

Never use abrasive scouring powder or steel wool pads, as they will scratch the surface.

A periodic coating of a high quality marine or automotive polish will help retain the finish.

### INSTALLATION QUESTIONS

Questions on the installation or missing parts, call 216-267-3100 or e-mail [customerservice@mustee.com](mailto:customerservice@mustee.com) for assistance. Hours of operation are Monday to Friday, 8:30 a.m. to 4:30 p.m. E.S.T.

Please have the installation manual available when calling. **DO NOT RETURN PRODUCT TO THE PLACE OF PURCHASE.**