

AXKT

Replacement for any damaged or lost sensor. For use with models listed below *

Replacement



Specifications

Dimensions: (Inside Diameter) .50"
(Outside) 2.05" x 1.46" x 1.50"

***Only For**

Use With: RIBXLCRA, RIBXLCRF, RIBXLSRA, RIBXLSRF, RIBXRA, RIBXRF

Purpose: Can replace any damaged or lost sensor.
For use with the models listed above.