





Example of composition:



A collection of fixed and modular upholstered furniture that can be used for both traditional and modern furnishing solutions using special peninsula pieces in various sizes. Thanks to an innovative system that adjusts the back to three positions, settees and armchairs can adopt different positions, creating seats of various depths and comfort. The variable density polyurethane foam structure is completed with comfortable reversible cushions in two different softnesses.

## Adjustable back positions



## Available finishes

Fabric, leather.

## Materials

### Structure interior

Frame made of solid Fir wood and chipboard, with elastic straps.

### Structure padding

High capacity variable density polyurethane foam. Light velvet cover.

### Seat cushions

Insert in shaped polyurethane and sterilised feathers. 100% cotton cover.

### Back cushions

Polyester fibre, sterilised feathers. 100% cotton cover.

### Feet


Shiny stainless steel.

### Table top

Veneered panel, covered with veneer, or covered with sheet melamine and painted in colours from the Molteni range.

### Outer cover


Removable



## Components


### Armchair

w.102 – d.102 – h.85 cm  
w.40<sup>1/8"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>




### Settee with adjustable back


w.182 – d.102 – h.85 cm  
w.71<sup>5/8"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>



w.202 – d.102 – h.85 cm  
w.79<sup>1/2"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>




w.222 – d.102 – h.85 cm  
w.87<sup>3/8"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>




### Settee with adjustable back


w.262 – d.102 – h.85 cm  
w.103<sup>1/8"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>



w.262 – d.102 – h.85 cm  
w.103<sup>1/8"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>




w.262 – d.102 – h.85 cm  
w.103<sup>1/8"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>



### Pouff

w.80 – d.102 – h.43 cm  
w.31<sup>1/2"</sup> – d.40<sup>1/8"</sup> – h.16<sup>7/8"</sup>



w.102 – d.102 – h.43 cm  
w.40<sup>1/8"</sup> – d.40<sup>1/8"</sup> – h.16<sup>7/8"</sup>




### End


w.130 – d.102 – h.85 cm  
w.51<sup>1/4"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>



w.190 – d.102 – h.85 cm  
w.74<sup>7/8"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>




w.190 – d.102 – h.85 cm  
w.74<sup>7/8"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>




### End


w.210 – d.102 – h.85 cm  
w.82<sup>3/4"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>



w.250 – d.102 – h.85 cm  
w.98<sup>3/8"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>




w.250 – d.102 – h.85 cm  
w.98<sup>3/8"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>




### Chaise longue

w.102 – d.220 – h.85 cm  
w.40<sup>1/8"</sup> – d.86<sup>5/8"</sup> – h.33<sup>1/2"</sup>




w.102 – d.152 – h.85 cm  
w.40<sup>1/8"</sup> – d.59<sup>7/8"</sup> – h.33<sup>1/2"</sup>




**Central**


w.118 – d.102 – h.85 cm  
w.46<sup>1/2"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>




w.178 – d.102 – h.85 cm  
w.70" – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>




w.178 – d.102 – h.85 cm  
w.70" – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>


**Central**


w.198 – d.102 – h.85 cm  
w.78" – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>




w.238 – d.102 – h.85 cm  
w.93<sup>3/4"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>



w.238 – d.102 – h.85 cm  
w.93<sup>3/4"</sup> – d.40<sup>1/8"</sup> – h.33<sup>1/2"</sup>


**Peninsula**

w.102 – d.240 – h.85 cm  
w.40<sup>1/8"</sup> – d.94<sup>1/2"</sup> – h.33<sup>1/2"</sup>




w.102 – d.140 – h.85 cm  
w.40<sup>1/8"</sup> – d.55<sup>1/8"</sup> – h.33<sup>1/2"</sup>


**Daybed**

w.200 – d.102 – h.43/95 cm  
w.78<sup>3/4"</sup> – d.40<sup>1/8"</sup> – h.16<sup>7/8"</sup> / 37<sup>3/8"</sup>

With removal internal tray  
in hide leather  
w.45 – d.70 – h.8 cm  
w.17<sup>3/4"</sup> – d.27<sup>1/2"</sup> – h.3<sup>1/8"</sup>



6-position back

**Additional  
cushions**


50x50 cm – 19<sup>3/4"</sup> x 19<sup>3/4"</sup>



60x60 cm – 23<sup>5/8"</sup> x 23<sup>5/8"</sup>



50x35 cm – 19<sup>3/4"</sup> x 13<sup>3/4"</sup>


**Compulsory with  
corner composition**


## Use and maintenance

The product was designed for use in domestic interiors; never stand on structural parts; avoid doing maintenance on components of the product yourself, contacting your retailer with regard to any problem that may arise.

Everyday use results in some compression of the padded parts during standard product life-span. The presence of any odours given off by the product when unpacked does not constitute a source of danger and disappears when the product is exposed to airy surroundings. When the product must be moved, keep it up off the floor to avoid damage to parts that rest on the floor. Keep tops from coming into contact with water or other liquids, even for brief periods of time. Borders should not be placed in the vicinity of sources of heat of over 45°C.

### Weekly maintenance

Fluff up seat and back cushions by hand, taking care to alternate the seat positions of the cushions used most often with the lesser used ones and periodically turning the seat cushions over (reversible cushions). To fluff cushions up, shake all sides of the cushion (sides, tops and bottoms). This should be done after removing the cushions from the structure for improved air circulation.



1. Remove the cushion and beat the surface with your hand working from the outside towards the centre



2. Replace the seat cushion and redistribute the feathers evenly



3. Beat the front of the seat padding at the front (all along) so as to restore correct alignment with the covers.



4. Remove the single back cushions and beat the outer sections (all sides) so as to reposition the feathers in the centre of the padding



5. Place the cushion on a flat surface and distribute the filling from the centre towards the sides

### Monthly maintenance

Remove covers and fluff up as indicated above. After doing this allow them to air, possibly outside, for about 30 minutes before replacing the covers.

### Maintenance - Covers

See covers information sheet (in the download section on the web site [www.molteni.it](http://www.molteni.it)).

### Shiny chrome finish foot maintenance

For ordinary maintenance use a soft dry cloth to remove dust. For greasy/oily dirt (fingerprints) treat the surfaces with standard window cleaning detergents containing ammonia. Every month, treat the surfaces with special metal cleaning/polishing products. Avoid products containing solvent and/or spirit and cloths with hard fibres (linen and synthetic) that could ruin and/or scratch the surfaces.

### Painted black finish foot maintenance

For ordinary maintenance use a soft dry cloth to remove the dust. For greasy/oily dirt (fingerprints) treat the surfaces with a wet sponge and washing-up liquid, then rinse with a damp, well squeezed cloth. All this should be done without applying too much pressure.

### Disposal

Once discarded, neither the product nor its components should be abandoned in an unauthorised area.

## Moving back

### Characteristics

Thanks to an innovatory reclining unit, the settees and armchairs in the Sistema Reversi offer three sitting positions of different depths and ergonomic positions. As well as the traditional position, there is one for conversation (back in horizontal position) and one for maximum relaxation (back vertical).

### General notes

It is possible to change from position 1 to positions 2 and 3 in sequence; from position 3 you must return to position 1 before changing position again. For correct use and to guarantee lasting functionality, follow these instructions carefully.



POSITION 1

#### Basic position

To adjust to position 2

Move the back cushions to allow the adjustable back to turn freely. Hold the back in the centre and turn to the horizontal position; a slight click means it has locked.




POSITION 2

#### Conversation position

To adjust to position 3

Hold the back and turn it outwards to the maximum height. A locking system prevents sudden movements.



POSITION 3

#### Relaxation position

To return to position 1

Hold the back in the centre and return to the standard position turning it inwards.

Any damage caused by incorrect use is not covered by the product guarantee.