




Note: Bulkhead combination must be used on a flat surface of a NEMA 4X Enclosure to maintain rating.




1 Bulkhead Opening Requirements




2 Inside of Enclosure Outside of Enclosure



3



4



Coupler Module Removal Instructions

