











### CONDUIT APPLICATION



### IN-WALL BOX DATA APPLICATION




BASE BREAKOUTS	RACEWAY
A	LDPH3, LDS3, LD3, PD3
B	LDPH5, LDS5, LD5, PD6
C	LDPH10, LD10
D	T45



COVER BREAKOUTS	RACEWAY	ADAPTER
W	T45	-
X	LDPH10, LD10	-
X	PD3	BA3
X	PD6	BA6
Y	LDPH5, LDS5, LD5	-
Z	LDPH3, LDS3, LD3	-

**COVER REMOVAL**



<p>For Instructions in Local Languages and Technical Support: <a href="http://www.panduit.com/resources/install_maintain.asp">www.panduit.com/resources/install_maintain.asp</a></p>	<p><b>PANDUIT</b> www.panduit.com</p>	<p>E-mail: techsupport@panduit.com Fax: 866-405-6654</p>
--	---	--