




## INSTALLATION INSTRUCTIONS T-PMPI-274-PC

© PANDUIT Corp. 2006

|                                                                                                     | RGESD-1Y | RGESD2-1 | RGESD2A-1 | RGESD2B-1 | RGESD2C-1 |
|-----------------------------------------------------------------------------------------------------|----------|----------|-----------|-----------|-----------|
|  One Hole ESD Port | 1        | -        | -         | -         | -         |
|  ESD Port           | -        | 1        | 1         | 1         | 1         |
|  ESD Sticker       | 1        | 1        | 1         | 1         | 1         |
|  12-24 Screw       | 1        | 2        | -         | -         | -         |
|  12-24 HDW         | -        | -        | -         | 2         | 2         |
|  M6 Screw        | 1        | 2        | -         | 1         | -         |
|  10-32 Screw     | 1        | -        | 2         | -         | -         |
|  M5 Screw        | 1        | -        | 2         | -         | -         |
|  Cage Nut HDW    | -        | -        | -         | 2         | -         |
|  Thru-Hole HDW   | -        | -        | -         | -         | 2         |
|  AntiOX           | 1        | 1        | 1         | 1         | 1         |
|  Cleaning Pad     | 1        | 1        | 1         | 1         | 1         |



For Instructions in Local Languages  
and Technical Support:

[http://www.panduit.com/resources/install\\_maintain.asp](http://www.panduit.com/resources/install_maintain.asp)