LATCH CAM REMOVAL

- 1. Use pliers as shown.
- 2. Squeeze tabs on latch cam with pliers.
- 3. Lift latch cam and push in direction shown.



A Pentair Company

Hoffman Enclosures Inc. 2100 Hoffman Way Anoka, MN 55303–1745 (763) 422–2211 Tel www.hoffmanonline.com



87567340