

LAG container



Description

Detection container for LAG leak detectors. The LAG container also serves as an expansion vessel. For aboveground tanks, the ratio between usable contents and total volume of leak detection fluid must be no more than 1:35. If the interstitial space has a greater volume, you must use additional containers.

Versions

		Part no.
LAG container white	●	40730
LAG container black	●	40731

- in-stock items
- Non-stock items