




STANDARD



- Dimensions are approximate. Unit dimensions should be checked before installation.
- Installation must be carried out according to the manufacturer's instructions.