


SNE SERIES

RISER BASE


ASSEMBLY

NOTE: Skip directly to step 4 when mounting the RIB without the VFEET and SANGLE.

- 1) Bolt the VFEET to the RIB using the supplied hardware.
- 2) Mount the VFEET to the floor:
Using the appropriate customer supplied hardware anchor VFEET/
RIB assembly to the floor.
- 3) Mount the SANGLE to the VFEET
using the supplied hardware bolt the SANGLE
to the VFEET, ensure the angle is level and
at the required height to support the raised
floor tiles.



NOTE: To remove the knockout, forcefully hit it with a metal hammer. Clean the edges with a screwdriver to avoid chafing wiring.




INSTALLATION CONTINUED

- 4) Remove factory installed leveling feet and casters from the rack.
- 5) Position the rack on the riser base and Install mounting brackets to the front and back of the rack, (4) places.
- 6) Install the (4) mounting bracket with supplied hardware.

NOTE: SANGLES and VFEET not shown

MOUNTING HARDWARE INCLUDED

<u>Part #</u>	<u>Description</u>	<u>Qty.</u>	<u>Usage</u>
A	5/16-18	8	Used to mount bracket to rack
B	3/8-18	4	Used to mount bracket to riser base



WARRANTY

Middle Atlantic Products (the "Company") warrants the Series Protection Module to be free from defects in material or workmanship under normal use and conditions for the lifetime of the product.

The Company's entire liability to the purchaser, and the purchaser's (or any other party's) sole and exclusive remedy, under this warranty shall be limited, at the Company's option, to either (a) return of and refund of the price paid for, or (b) repair or replacement at the Company's factory of the products purchased, or any part or parts thereof, which the Company has determined to be defective after inspection thereof at the Company's factory.

This warranty does not cover damage due to acts of God, accident, misuse, abuse or negligence by parties other than the Company, or any modification or alteration of the products. In addition, this warranty does not cover damage due to improper handling, assembly, installation or maintenance.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF THE PRODUCTS PURCHASED, EVEN IF THE COMPANY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE COMPANY'S LIABILITY TO THE PURCHASER (OR ANY OTHER PARTY) HEREUNDER, IF ANY, SHALL IN NO EVENT EXCEED THE PURCHASE PRICE OF THE PRODUCTS PAID TO THE COMPANY.

Corporate Headquarters

Corporate Voice 973-839-1011 - Fax 973-839-1976
International Voice +1 973-839-8821 - Fax +1 973-839-4982
middleatlantic.com - info@middleatlantic.com

Middle Atlantic Canada

Voice 613-836-2501 - Fax 613-836-2690
middleatlantic.ca - customerservicecanada@middleatlantic.ca

Factory Distribution

USA: NJ - CA - IL Canada: ON - BC