


---

# INSTALLATION INSTRUCTIONS

---



---

## Side Shelf Accessory

---

## DISCLAIMER

Legrand | AV and its affiliated corporations and subsidiaries (collectively "Legrand | AV"), intend to make this manual accurate and complete. However, Legrand | AV makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand | AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand | AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Legrand AV Inc.

## DEFINITIONS

**MOUNTING SYSTEM:** A MOUNTING SYSTEM is the primary Chief product to which an accessory and/or component is attached.

**ACCESSORY:** AN ACCESSORY is the secondary Chief product which is attached to a primary Chief product, and may have a component attached or setting on it.

**COMPONENT:** A COMPONENT is an audiovisual item designed to be attached or resting on an accessory or mounting system such as a video camera, CPU, screen, display, projector, etc.

**WARNING:** A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.

**CAUTION:** A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.

## ! IMPORTANT SAFETY INSTRUCTIONS!

**WARNING:** Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all mounting systems/accessories are properly assembled and installed using the instructions provided.

**WARNING:** Failure to provide adequate structural strength for this accessory can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this accessory is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the accessory.


**WARNING:** Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all equipment and accessories mounted on the FCA850 does not exceed 5 lbs (2.27 kg).

**WARNING:** RISK OF INJURY TO PERSONS! Do not use this accessory to support video equipment such as televisions or computer monitors.













**WARNING:** Do not use this accessory outdoors.

**--SAVE THESE INSTRUCTIONS--**


## DIMENSIONS




## LEGEND

	<b>Tighten Fastener</b> Apretar elemento de fijación Befestigungsteil festziehen Apertar fixador Serrare il fissaggio Bevestiging vastdraaien Serrez les fixations		<b>Pencil Mark</b> Marcar con lápiz Stiftmarkierung Marcar com lápis Segno a matita Potloodmerkteken Marquage au crayon
	<b>Loosen Fastener</b> Aflojar elemento de fijación Befestigungsteil lösen Desapertar fixador Allentare il fissaggio Bevestiging losdraaien Desserrez les fixations		<b>Drill Hole</b> Perforar Bohrloch Fazer furo Praticare un foro Gat boren Percez un trou
	<b>Phillips Screwdriver</b> Destornillador Phillips Kreuzschlitzschraubendreher Chave de fendas Phillips Cacciavite a stella Kruiskopschroevendraaier Tournevis à pointe cruciforme		<b>Adjust</b> Ajustar Einstellen Ajustar Regolare Afstellen Ajuster
	<b>Open-Ended Wrench</b> Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche		<b>Remove</b> Quitar Entfernen Remover Rimuovere Verwijderen Retirez
	<b>By Hand</b> A mano Von Hand Com a mão A mano Met de hand À la main		<b>Optional</b> Opcional Optional Opcional Opzionale Optie En option
	<b>Hex-Head Wrench</b> Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada Chiave esagonale Zeskantsleutel Clé à tête hexagonale		<b>Security Wrench</b> Llave de seguridad Sicherheitsschlüssel Chave de segurança Chiave di sicurezza Veiligheidssleutel Clé de sécurité

TOOLS REQUIRED FOR INSTALLATION



PARTS



## Installation

**NOTE:** The FCA850 camera shelf can be mounted before or after the display is mounted to the faceplate. It may be mounted to either side of the display.

### Shelf Assembly

1. Use two #10-24 x 3/8" button head cap screws (B) to secure camera shelf bracket (E) to vertical bracket (H). (See Figure 1)
2. Use two #10-24 x 3/8" button head cap screws (B) to secure shelf (A) to shelf bracket (E). (See Figure 1)




Figure 1

3. Use two 5/16-18 x 1/2" button head cap screws (C) to secure vertical bracket to two extension bars (F). (See Figure 2)




Figure 2

### Attach to Rails

1. Remove end covers from existing mounting system. (See Figure 3)




Figure 3

2. Slide rail bushings (G) onto extension bars (F). (See Figure 4)
3. Install two 5/16-18 x 1/2" button head cap screws (C) into ends of extension bars (F) to keep bushings (G) from sliding off bars. (See Figure 4)




Figure 4

4. Insert ends of extension bars (F) into open endings of mounting system. (See Figure 5)
5. Tighten bushings (G) to secure extension bars (F) to mounting system at desired location. (See Figure 5)




Figure 5

## Camera Mounting



**WARNING:** Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all equipment and accessories mounted on the FCA850 does not exceed 5 lbs (2.27 kg).

**NOTE:** Mounting options will vary depending on the type of camera being mounted.

1. Install 1/4-20 x 1/4" Phillips pan machine screw (D) through holes on shelf and into hole on bottom of camera. (See Figure 6)

**NOTE:** Camera can be secured to mount by threading a tie through outside slots on camera mount and around the camera.

**NOTE:** It is also acceptable to mount the camera directly to the shelf without any screws or ties.




Figure 6

## Adjustments

### Extension Length Adjustment

1. Loosen two bushings (G) connecting extension bars (F) to mount. (See Figure 7)
2. Adjust arm to desired length. (See Figure 7)
3. Tighten two bushings (G) until connection to mount is secure. (See Figure 7)




Figure 7



**CHIEF®**

A brand of  **legrand®**

8800-003208 Rev02  
©2024 Legrand | AV  
[www.legrandav.com](http://www.legrandav.com)  
08/2024

- |                          |          |   |
|--------------------------|----------|---|
| <b>USA/International</b> | <b>A</b> | 6436 City West Parkway, Eden Prairie, MN 55344  |
|                          | <b>P</b> | 800.582.6480 / 952.225.6000   |
|                          | <b>F</b> | 877.894.6918 / 952.894.6918   |
| <b>Europe</b>            | <b>A</b> | Franklinstraat 14, 6003 DK Weert, Netherlands   |
|                          | <b>P</b> | +31 (0) 495 580 852   |
|                          | <b>F</b> | +31 (0) 495 580 845   |
| <b>Asia Pacific</b>      | <b>A</b> | Office No. 918 on 9/F, Shatin Galleria<br>18-24 Shan Mei Street<br>Fotan, Shatin, Hong Kong |
|                          | <b>P</b> | 852 2145 4099   |
|                          | <b>F</b> | 852 2145 4477   |

