
# INSTALLATION INSTRUCTIONS



**VESA Tablet Tabletop Stand** 



**HTSVS** 

**HTSVS** Installation Instructions

#### **DISCLAIMER**

Legrand | AV and its affiliated corporations and subsidiaries (collectively "Legrand | AV"), intend to make this manual accurate and complete. However, Legrand | AV makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand | AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand | AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Legrand AV Inc.

#### **DEFINITIONS**

MOUNTING SYSTEM: A MOUNTING SYSTEM is the primary Chief product to which an accessory and/or component is attached.

**ACCESSORY:** AN ACCESSORY is the secondary Chief product which is attached to a primary Chief product, and may have a component attached or setting on it.

**COMPONENT:** A COMPONENT is an audiovisual item designed to be attached or resting on an accessory or mounting system such as a video camera, CPU, screen, display, projector, etc.



WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.



**CAUTION:** A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



### IMPORTANT SAFFTY INSTRUCTIONS

WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all mounting systems are properly assembled and installed using the instructions provided.



WARNING: Failure to provide adequate structural strength for this mounting system can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this mounting system is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the mounting system.

WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components and accessories attached to mounting system does not exceed 7 lbs (3.18 kg) if free-standing or 15 lbs (6.8 kg) if secured to a tabletop.

WARNING: Use this mounting system only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.



WARNING: Never operate this mounting system if it is damaged. Return the mounting system to a service center for examination and repair.




**WARNING:** Do not use this mounting system outdoors.

WARNING: RISK OF INJURY TO PERSONS! Do not use this mounting system to support video equipment such as televisions or computer monitors.


--SAVE THESE INSTRUCTIONS--

Installation Instructions HTSVS

# **DIMENSIONS**




#### **LEGEND**




Installation Instructions HTSVS

# **TOOLS REQUIRED FOR INSTALLATION**



## **PARTS**



# **Assembly And Installation**

WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components and accessories attached to mounting system does not exceed 7 lbs (3.18 kg) if free-standing or 15 lbs (6.8 kg) if secured to a tabletop.

 Use two #10-24 lock nuts (H) to install VESA adapter (D) to column (A). (See Figure 1)




Figure 1

- Connect cord to bottom of column-mounted tablet. (See Figure 2)
- 3. Partially install four #10-24 x 5/8" button head cap screws (C) into column cover (B). (See Figure 2)
- Insert column cover (B) into column (A) channel and place four screws (C) into four holes on column cover (B). (See Figure 2)




Figure 2

- 5. Slide column cover (B) up until screws (C) are properly positioned into keyholes. (See Figure 3)
- Tighten all four screws (C) to secure column cover (B) to column (A). (See Figure 3)




Figure 3

**WARNING:** Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components and accessories attached to mounting system does not exceed 7 lbs (3.18 kg) if free-standing or 15 lbs (6.8 kg) if secured to a tabletop.

- 7. Select proper length screw to use for tablet being installed.
- 8. Use two selected screws (E, F or G) into lower two mounting holes on tablet. (See Figure 4)
- Insert two installed screws (E, F or G) into lower drop holes on VESA adapter (D). (See Figure 4)




Figure 4

Installation Instructions HTSVS

 Use two selected screws (E, F or G) to secure table to VESA adapter (D). (See Figure 5)




Figure 5

## **Bolt to Table (Optional)**

The HTSVS mount may be bolted to the table for increased security or stability. It is also required if the tablet weighs more than 7 lbs (3.18 kg). Hardware is NOT provided for this installation.

**IMPORTANT!**: Column cover (B) must be attached to column (A) before being bolted to table.

- Use column holes as a template to mark holes on table at desired mounting location.
- Drill holes at marked locations according to instructions of hardware being used for installation. (See Figure 6)
- 3. Use hardware (not included) to secure base of column (A) to floor. (See Figure 6)




Figure 6

### **Tilt Adjustment**

- Loosen tilt adjustment knobs on VESA adapter (D) by turning them counter-clockwise. (See Figure 7)
- 2. Tilt to desired position. (See Figure 7)
- Tighten tilt adjustment knobs on VESA adapter (D) by turning them clockwise. (See Figure 7)




Figure 7

# **Rubber Feet Installation (Optional)**

**NOTE:** Up to six rubber feet (E) may be installed to bottom of base for increased stability.

 Remove adhesive from behind rubber feet (E) and install feet on underside of base. (See Figure 8)

**NOTE:** Place two front feet as far forward as possible and two rear feet as far back as possible to maintain stability. Remaining feet can be omitted or placed as desired to stabilize the stand.




Figure 8

**HTSVS** Installation Instructions



A brand of Lilegrand

8800-003265 Rev02 ©2021 Legrand | AV www.legrandav.com 02/2021

**USA/International** A 6436 City West Parkway, Eden Prairie, MN 55344

800.582.6480 / 952.225.6000

**F** 877.894.6918 / 952.894.6918

A Franklinstraat 14, 6003 DK Weert, Netherlands

+31 (0) 495 580 852

+31 (0) 495 580 845

**Asia Pacific** 

**Europe** 

A Office No. 918 on 9/F, Shatin Galleria

18-24 Shan Mei Street Fotan, Shatin, Hong Kong

**P** 852 2145 4099

F 852 2145 4477

