




01.
Vent locked



02.
Turn handle 90° to unlock



03.
Open vent
Vent will lock in 100mm position




04.
Turn handle back to
unlock mechanism



05.
Vent can be opened to 15°
Handle can be turned back to 90° position
No lock in this position
If wind then vent may close and stop @ 100mm position and lock again



06.
When closing vent will lock
@ 100mm position



07.
Turn handle back to
unlock mechanism



08.
Close vent
During closing, turn back handle
to 90° position



09.
Turn handle to lock vent

