


# Cordia – LED Ceiling Light Dimmable 19309 19310 19314

# THIS FITTING MUST BE INSTALLED BY A QUALIFIED ELECTRICAL CONTRACTOR in accordance with the latest AS/NZS 3000 and relevant amendments

Before first using your new Brilliant product it is most important that you read and follow these instructions, even if you feel you are quite familiar with this type of product. Keep this document handy for future reference.

## For Your Safety

- To prevent electrical shock, please ensure that power is DISCONNECTED before installing.
- During use the light shade and/or light assembly may become hot.
- Do not install in a position where the fitting can be easily accessed by children or the infirm.
- Do not touch any parts of the assembly with bare hands while it is 'ON'.
- Be aware of the height of your installation. Refer to 'Working at Heights " guide from your local or State Authorities.
- Any alterations or additions to building wiring must be completed by a licensed electrician or person authorised by legislation to work on the fixed wiring of any electrical installation.



Dimmers	Products		
	19309	19310	, 19314
LUMEX LOADSMART	YES	YES	N/A
BRILLIANT ROTARY	YES	YES	, N/A
CABAC HNS630DT	YES	YES	YES
CLIPSAL 4062E450UDM	YES	YES	YES
CLIPSAL 32E450UD	YES	YES	YES
CLIPSAL 32E450TM	YES	YES	YES
CLIPSAL 31E4RUD	YES	YES	YES*
CLIPSAL 31E2PUD	YES	YES	YES*
HPM EM400A3P	YES	YES	YES*
HPM EM400A2P	YES	YES	YES
HPM EM250T	YES	YES	N/A
BRILLIANT PUSHBUTTON	YES	YES	YES*
CLIPSAL 32ELEDM	YES	YES	N/A

### INSTALLATION INSTRUCTIONS

1. Ensure mains supply is switched off.

2. Unpack the fixture (A) carefully and place it on a flat surface.

3. Remove the diffuser (B) by gently rotating it anticlockwise and lifting it from the fixture.

4. Drill holes in the ceiling using the holes (C) in the fixture as a template.

5. Use screws and suitable fixture system to secure the fixture to the ceiling ensuring that the mains cable passes through the entry hole (D).

6. Connect the Live(L). Neutral(N) and Earth 🚽

according to the markings on the terminal block (F).

7. Ensure that all terminations are firm and the terminal block cover is replaced over the block.

8. Install the diffuser by aligning the slots (G) in the diffuser with the pins (H) on the inside of the fixture.

Gently rotate clockwise to secure diffuser.

9. Switch on the mains supply.

10. Switch on the light at the wall switch.

#### WARNING:

- Not designed for outdoor use.
- This fitting must be earthed.
- Failure to follow these instructions may result in breakages and will invalidate warranty.
- For safety reasons, any installation, repair or inspection must be done by a qualified electrician or electrical contractor, in accordance with Australian Standards.
- If product is functioning irregularly, please TURN OFF the power and contact the nearest authorized dealer.
- Do not perform unauthorised modification to the light fixture.
- Maintenance: Occasionally turn power off remove diffuser and wipe inside of diffuser with damp cloth. Allow to dry and replace. Do not allow water onto LED drive or LEDs.

#### DIMMING ADVISE:

- In order to make sure the light is working properly at low brightness, adjust the dimmer to Maximum brightness before reducing it to minimum.
- \*Programmable Dimmers Program your dimmer to make sure the minimum brightness is above 5%.



# Cordia – LED Ceiling Light Dimmable 19309 19310 19314

SPECIFICATIONS:		
Fitting:	Mild Steel/Acrylic	
LED Array:	19309: 800lm 12W 4200K (260mm)	
	19310: 1200lm 18W 4200K (320mm)	
	19314: 1650lm 24W 4200K (380mm)	
CRi:	85	
Protection:	Class I: Must be earthed	
Voltage:	230-240Vac 50Hz	
Use:	Indoor	

### Warranty:

Brilliant Lighting warrants this product against defects in manufacture and workmanship for a period of 3 year from date of purchase or as specified on the packaging. For products used in non-domestic or commercial applications, Brilliant Lighting warrants this product for a period of 3 months from date of purchase. This warranty is only valid for products installed and operated within the guidelines specified by Brilliant Lighting, and within the correct operating voltage ran ges as stated on the product's rating label.

Warranty does not include damage or loss arising from incorrect installation, operation or maintenance of this product, damage caused through modification, incorrect installation, service by unqualified or unauthorised personnel or lack of regular maintenance and cleaning. Proof of installation by qualified personnel may be required, e.g. Electrical Safety Certificate. Proof of purchase must be supplied with all warranty claims.

This warranty is provided in addition to any other rights and remedies of the customer under any law. In applications not intended for household, personal or domestic use, liability is limited to replacement or reimbursement of product only. Brilliant Lighting does not warranty the costs of removal or re-installation of this product or associated components.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure.

Any claim under this warranty must be made within the specified warranty period from date of purchase of this product. To make a claim under the warranty; at your own expense take the product (with proof of purchase – receipt or similar) to the store where you purchased the product or contact Brilliant Lighting at the address below.

This warranty is given by:

Brilliant Lighting (Aust) Pty. Ltd. ABN 37 006 203 694 956 Stud Road Rowville, VIC 3178 Phone: 03 9765 2555 Email: info@brilliant-lighting.com.au MADE IN CHINA