

GUIDE D'ASSEMBLAGE


ASSEMBLY GUIDE

11003309

Astella

A  X14	B  X14	C  X12	D  14 MM X26	E  M5 X 40 MM X11	F  X1	G  M3 X 12 MM X4
H  M6 X 25 MM X8	J  M6 X 12 MM X16	K  25 MM X8	L  X4	M  30 MM X2	N  X14	O  X1
P  X2	Q  M4 X 22 MM X4	R  X2	S  X2	T  X4	U  X4	

1 X2



2 X2



3 X2



4 X1



5 X1




6 X1




7 X1




8 X1




9 X1




10 X1



11 X1




12 X2



13 X1



14 X1




1 year
GARANTIE
WARRANTY

MISES EN GARDE : Assurez-vous d'avoir toutes les pièces en main. Manipulez les pièces et les outils avec soin. Assemblez le produit sur une surface plane et propre.

WARNINGS: Make sure you have all the parts in hand. Handle parts and tools with care. Assemble the product on a clean, flat surface.

1


- E  X3
- F  X1



VISSEZ COMPLÈTEMENT
SCREW COMPLETELY




UTILISATION
DU RACCORD
À CAME
HOW TO USE
CAM LOCK



2

- A  X4
- B  X4
- C  X2
- N  X4




VISSEZ COMPLÈTEMENT
SCREW COMPLETELY



3


- A  X2
- B  X2
- C  X1
- N  X2



VISSEZ COMPLÈTEMENT
SCREW COMPLETELY





UTILISATION
DU RACCORD
À CAME
HOW TO USE
CAM LOCK



4

- A  X5
- B  X4
- C  X2
- N  X4




VISSEZ COMPLÈTEMENT
SCREW COMPLETELY




5

- A  X3
- B  X2
- C  X1
- N  X2




6



7



- C  X6
- E  X8
- F  X1



VISSEZ COMPLÈTEMENT
SCREW COMPLETELY





8



VISSEZ PARTIELLEMENT
SCREW PARTIALLY





9





VISSEZ PARTIELLEMENT
SCREW PARTIALLY



10



11




VISSEZ COMPLÈTEMENT LES
PIÈCES DES ÉTAPES 8, 9 ET 11.
COMPLETELY SCREW THE PARTS
FROM STEPS 8, 9 AND 11.



12

- D X4
- T X2




VISSEZ COMPLÈTEMENT
SCREW COMPLETELY



13

- Q X2
- S X1




VISSEZ COMPLÈTEMENT
SCREW COMPLETELY




14

- D X16




VISSEZ COMPLÈTEMENT
SCREW COMPLETELY




15

- B  X2
- D  X4
- G  X4
- N  X2
- P  X2
- U  X4




16

- M  X2
- R  X2



17

CHARGE MAXIMALE
MAXIMUM LOAD :
22 LB (10 KG)



CHARGE MAXIMALE
MAXIMUM LOAD :
110 LB (50 KG)

CHARGE MAXIMALE
MAXIMUM LOAD :
22 LB (10 KG)

CHARGE MAXIMALE
MAXIMUM LOAD :
55 LB (25 KG)

AJUSTEZ LES VIS
ADJUST THE SCREWS