
















PORTE- VÊTEMENTS


CLOTHING RACK




GUIDE D'ASSEMBLAGE
ASSEMBLY GUIDE
11004153

A  X1	B  X1	C  X1	D  X1	E  X1
F  X1	G  X1	H  X1		
I  X2	J  X1	K  X3		
L  X8	M  X6	N  X2	O  X24	
P  X3	Q  X28	R  X1		


1




2




3



4



5



6

