

Dusk-to-Dawn LED Light

Models: 8813 / 8814

Dated receipt required for warranty replacement.

FEATURES

- · Bright, energy saving LED light
- · Automatically operates at night only
- · Adjustable Color Temperature from Warm White to Daylight settings



Note: All illustrations show model 8813. The instructions are the same for all models.

UNPACKING

Be sure to remove all contents from packaging and verify all items are present before assembling this light fixture. This package includes the following items:

- · Dusk-to-dawn LED light.
- · Owner's Manual
- · Mounting Hardware

HARDWARE INCLUDED


Note: Four mounting bracket screws are included. The installation will only require two. Discard the unused mounting bracket screws after installation.




Plastic plug










Mounting Bolt (Pre-Installed in Light Fixture)



#8 Mounting Bracket Screw (x2)



Wire Connector (x3)



Mounting Bracket

IMPORTANT SAFETY AND INSTALLATION INFORMATION


Before installing security light, read all instructions carefully and keep owner's manual for future reference.

- WARNING: To prevent electric shock, ensure that the power is disconnected before installation.
- WARNING: Risk of fire. Keep the lamp heads at least 2 in. from combustible materials.
- CAUTION: Burn hazard. Allow the light fixture to cool before touching.
- This light fixture requires 120-volts AC.
- · This light fixture must be properly grounded.
- Some electrical codes require installation by a qualified electrician.
- This fixture is designed for outdoor installation and should be mounted to a wall or eaves.
- To achieve best results, this fixture should be mounted 8 feet (2.4 meters) above the ground.
- Ensure the photocell on the light fixture is positioned as shown when mounting the light on the wall or eaves.

WIRING

WARNING: Turn power off at circuit breaker or fuse. Place tape over circuit breaker switch and verify power is off at the fixture.

- Remove the existing light fixture.
- Install the mounting bracket with the stamped word "FRONT" facing away from the junction box (see Figure 1). Use the mounting bracket screws that best fit the junction box.
- 3. Connect all ground wires to the pigtail wire attached to the green ground screw (see Figure 2).
- Twist the junction box wires and fixture wires together as shown.
 Secure with wire connectors (see Figure 2).
 - · White to White
 - · Black to Black



Eave Mount




Figure 1




Figure 2

FINAL ASSEMBLY

- 1. Double check that all wiring connections are securely connected.
- Align the mounting bolt on the back of the fixture with the center hole in the mounting bracket. Note: The mounting bolt is designed to stay in the light fixture.
- Tighten the mounting bolt securely being careful not to overtighten (see Figure 3).
- Push the rubber plug firmly into the mounting bolt hole on the light fixture (see Figure 3).
- 5. Caulk around mounting plate and mounting surface with silicone weather sealant (see Figure 4).
- 6. Turn on the circuit breaker and light switch.
- To test the light during daylight, cover the photocell with black tape and ensure the light works properly.
- 8. Uncover the photocell and your unit will operate automatically on at dusk, off at dawn.
- If needed, gently grasp the lamp heads and tilt them up or down or side to side to adjust the light coverage area (see Figure 5).

CAUTION: Burn hazard. Allow the light fixture to cool before touching.

OPERATION

Set the Adjustable Color Temperature dial to the desired light color (see Figure 6).

- Turn the Adjustable Color Temperature dial toward the "Blue" color to increase the color temperature toward daylight (5000K).
- Turn the Adjustable Color Temperature dial toward the "Orange" color to decrease the color temperature toward warm (3000K).

CARE AND CLEANING

- To prolong the original appearance, clean the light fixture with clear water and a soft, damp cloth only.
- Do not use paints, solvents, or other chemicals on this light fixture.
 They could cause a premature deterioration of the finish. This is not a defect in the finish and will not be covered by the warranty.
- Do not spray the light fixture with a hose or power washer.




Figure 3




Figure 4





Figure 5



SPECIFICATIONS

Power Requirements	120 VAC, 60 Hz
Lumens:	
Model 8813	1850 LM
Model 8814	3100 LM
LED color temperature	Adjustable: 2700K to 5000K
Wattage:	
Model 8813	24 W
Model 8814	36 W

TROUBLESHOOTING GUIDE

SYMPTOM	POSSIBLE CAUSE	SOLUTION
The light will not come on.	 Light switch is turned off. Fuse is blown or circuit breaker is turned off. Daylight turn-off (photocell) is in effect. The circuit wiring is incorrect, if this is a new installation. 	 Turn light switch on. Replace fuse or turn circuit breaker on. Recheck after dark or cover photocell with black tape to test (see <i>Final Assembly</i>, step 7). Verify wiring is correct.
The light comes on during the day.	The light may be installed in a relatively dark location.	The light fixture is operating normally under these circumstances. To test, shine a flashlight at the photocell. The light should turn off.
The lights stay on continuously.	The light may be installed in a relatively dark location.	The light fixture is operating normally under these circumstances. To test, shine a flashlight at the photocell. The light should turn off.

TECHNICAL SERVICE

Please call 1-800-858-8501 (English speaking only) for assistance before returning product to store.

If you experience a problem, follow this guide. You may also want to visit our Web site at: www.hzsupport.com. If the problem persists, call* for assistance at 1-800-858-8501 (English speaking only), 8:00 AM to 5:00 PM CST (M-F). You may also write* to:

HeathCo LLC, P.O. Box 90045, Bowling Green, KY 42102-9045

ATTN: Technical Service

No Service Parts Available for this Product

Please keep your dated sales receipt, it is required for all warranty requests.

^{*} If contacting Technical Service, please have the following information available: Model Number, Date of Purchase, and Place of Purchase.

FIVE YEAR LIMITED WARRANTY

This is a "Limited Warranty" which gives you specific legal rights. You may also have other rights which vary from state to state or province to province.

For a period of five years from the date of purchase, any malfunction caused by factory defective parts or workmanship will be corrected at no charge to you.

Not Covered - Repair service, adjustment and calibration due to misuse, abuse or negligence, light bulbs, batteries, and other expendable items are not covered by this warranty. Any damage to the light fixture resulting from the use of chemicals or a pressure washer machine are not covered by this warranty. Unauthorized service or modification of the product or of any furnished component will void this warranty in its entirety. This warranty does not include reimbursement for inconvenience, installation, setup time, loss of use, unauthorized service, or return shipping charges. This warranty covers only HeathCo LLC assembled products and is not extended to other equipment and components that a customer uses in conjunction with our products.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY, REPRESENTATION OR CONDITION OF MERCHANT ABILITY OR THAT THE PRODUCTS ARE FIT FOR ANY PARTICULAR PURPOSE OR USE, AND SPECIFICALLY IN LIEU OF ALL SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES. REPAIR OR REPLACEMENT SHALL BE THE SOLE REMEDY OF THE CUSTOMER AND THERE SHALL BE NO LIABILITY ON THE PART OF HEATHCO LLC FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO ANY LOSS OF BUSINESS OR PROFITS, WHETHER OR NOT FORESEEABLE. Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Please keep your dated sales receipt, it is required for all warranty requests.

HeathCo LLC reserves the right to discontinue products and to change specifications at any time without incurring any obligation to incorporate new features in products previously sold.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAN ICES-005 (B) / NMB-005 (B)

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Purchase Information Información de la compra Renseignements d'achat

Model #:	Date of Purchase:
Nº de modelo / N° de modèle	Fecha de compra / Date d'achat

Staple Purchase Receipt Here
Engrape aquí el recibo de compra
Agrafez le reçu d'achat ici

PLEASE KEEP YOUR DATED SALES RECEIPT,
IT IS REQUIRED FOR ALL WARRANTY REQUESTS.

POR FAVOR GUARDE SU RECIBO DE VENTA FECHADO; SE LO REQUIERE PARA CUALQUIER SOLICITUD DE GARANTÍA.

VEUILLEZ CONSERVER LE REÇU PORTANT LA DATE D'ACHAT; VOUS EN AUREZ BESOIN POUR TOUTES VOS DEMANDES LIÉES À LA GARANTIE.