


PIÈCES DE REMPLACEMENT
REPLACEMENT PARTS



BRIGITTA
3051587
TS2302

TASSILI.CA

FINI CHROME
CHROME FINISH



TASSILI SUPRA®