


PIÈCES DE REMPLACEMENT
REPLACEMENT PARTS



BRIGITTA
33003018
TS2310
TASSILI.CA

FINI CHROME
CHROME FINISH



TASSILI SUPRA®