


DOUCHE
SHOWER

PIÈCES DE REMPLACEMENT
REPLACEMENT PARTS

N° NO	PIÈCE PART		CODE
1	Panneau mural Wall panel	F02101-01	N/A
2	Finition d'extrusion centrale Central extrusion finish	FS00303-04	33003440
3	Extrusion centrale Central extrusion	FS00304-02	33003441
4	Base de douche Shower base	CDT253-01	N/A
5	Extrusion murale Wall extrusion	S261-07	33003461
6	Panneau fixe Fixed panel	S260-03	N/A
7	Rail supérieur Top track	F77045-01	33003456
8	Panneau de porte Door panel	K1100EV610BL02	N/A
A1	Vis ST4 X 30 MM ST 4 X 30 MM screw	F61507-01	N/A
A2	Vis ST4 X 30 MM ST 4 X 30 MM screw	F61011-01	N/A
A3	Vis ST4 X 10 MM ST 4 X 10 MM screw	F61514-01	N/A
A4	Vis M5 X 10 MM M5 X 10 MM screw	F61544-01	N/A
A5	Vis M5 X 16 MM M5 X 16 MM screw	F61545-01	N/A
B1	Ancrage mural Wall anchor	F66010-01	N/A
B2	Guide de panneau fixe Fixed panel guide	F66840-0W + F66387-0W	33003444
B3	Finition de guide de panneau fixe Fixed panel guide finish	F66842-0W	33003445
B4	Capuchon d'extrusion murale Wall extrusion cap	F66338-0C	33003451
B5	Capuchon d'extrusion Extrusion cap	F66337-0C	33003452
B6	Cache-vis Cover cap	F66011-0C	33003453
B7	Finition de drain Drain finish	F80003-0W	33003442
C1	Guide du pivot supérieur Top pivot guide	F82159-0C	33003454
C2	Pivot de panneau de porte Door panel pivot	F82160-0C	33003455
C3	Guide du pivot inférieur Bottom pivot guide	F66836-0W	33003446
C4	Ensemble de fixation du rail supérieur Top track mounting kit	F66844-0C	33003457
C5	Finition du guide de pivot inférieur Bottom pivot guide finish	F82161-0W	33003447
H1	Poignée Handle	F75130-0C	33003450
H2	Barre murale de tablette Shelf wall bar	F54032-1C	33003449
H3	Drain Drain	F27213-01	33003443
H4	Tablette Shelf	F76022-0W	33003448
L1	Joint de porte Door gasket	FS00572-01	33003458
L2	Ens. de joints d'étanchéité magnétiques Magnetic door seal kit	FS00602-50	33003460
L3	Joint d'étanchéité inférieur Bottom door gasket	FS00103-04	33003459



BAIKAL
33003271
T2410

FINI CHROME ET BLANC
CHROME AND WHITE FINISH



TASSILI.CA

TASSILI®