


DOUCHE SHOWER

PIÈCES DE REMPLACEMENT

REPLACEMENT PARTS

N° NO	PIÈCE PART		CODE
1	Rail Track	S496	33004158
2	Extrusion murale Wall extrusion	S495	33004159
3	Panneau fixe Fixed panel	S1416	N/A
4	Panneau de porte Door panel	K1100AV620BL02	N/A
5	Panneau mural Wall panel	F02156-01	N/A
6	Finition d'extrusion centrale Central extrusion finish	FS303	N/A
7	Base de douche Shower base	CDT227	N/A
8	Finition de drain Drain finish	F80003-0W	33003442
9	Extrusion centrale Central extrusion	FS304	N/A
10	Vis ST4 X 30 MM ST4 X 30 MM screw	F61507-01	N/A
11	Vis ST4 X 12 MM ST4 X 12 MM screw	F61052-01	N/A
12	Vis M4 X 30 MM M4 X 30 MM screw	F61411-01	N/A
13	Vis M4 X 30 MM M4 X 30 MM screw	F61011-01	N/A
14	Ancrage mural Wall anchor	F66010-01	N/A
15	Cache-vis Cover cap	F66317-0B	33004149
16	Joint de panneau fixe Fixed panel gasket	FS00219	33004157
17	Joint de panneau de porte Door panel gasket	FS00617	33004156
18	Joint d'étanchéité magnétique Magnetic door seal	FS00602	33004155
19	Capuchon d'extrusion murale Wall extrusion cap	F66323-02	33004145
20	Capuchon d'extrusion gauche Left extrusion cap	F66322-L2	33004143
21	Capuchon d'extrusion droit Right extrusion cap	F66322-R2	33004144
22	Roulettes supérieures Top rollers	F78731-03	33004151
23	Roulettes inférieures Bottom rollers	F78732-03	33004152
24	Poignée Handle	F75130	33004153
25	Ensemble de 3 tablettes Set of 3 shelves	F76015-0B	33004142
26	Drain Drain	F27213-01	33003443



BAIKAL
33004141
2510

FINI BLANC ET NOIR
WHITE AND BLACK FINISH



TASSILI.CA

TASSILI®