


Feuerschale



Sehr geehrter Kunde,

wir gratulieren Ihnen zum Erwerb Ihres Gerätes. Lesen Sie die folgenden Hinweise sorgfältig durch und befolgen Sie diese, um möglichen Schäden vorzubeugen. Für Schäden, die durch Missachtung der Hinweise und unsachgemäßen Gebrauch entstehen, übernehmen wir keine Haftung.

Sicherheitshinweise

- Die Feuerschale ist zum Entfachen von Feuer oder Glut bestimmt.
- Halten Sie Kinder und Haustiere vom Feuer fern.
- Stellen Sie die Feuerschale nicht in der Nähe von leicht entzündlichen Gegenständen auf.
- Nur Erwachsene dürfen ein Feuer entfachen.
- Achten Sie darauf, dass Ihre Kleidung kein Feuer fängt.
- Lassen Sie das Feuer nicht unbeaufsichtigt.
- Ersticken Sie die Glut am Ende vollständig.

Lieferumfang

- 1 Feuerschale
- 3 Standbeine
- 2 Griffe

- 6 Sechskantmuttern
- 4 Schrauben
- 4 Unterlegscheiben

A	3	
D	1	
G	2	
S 1	6	©
S2	4	
S 3	4	®
S4	6	0



Montage

Benötigtes Werkzeug

- Schraubenschlüssel
- Schraubendreher

Schritt 1: Befestigung der Standfüße


- Führen Sie einen Standfuß mit den beiden Gewinden durch die Bohrungen der Schale.
- 2. Legen Sie von oben zwei Unterlegscheiben (S4) auf die durchgeführten Gewinde.
- 3. Schrauben Sie jeweils eine Sechskantmuttern auf das Gewinde.
- 4. Wiederholen Sie die Schritte 1-3 für jeden Standfuß.


Schritt 2: Befestigung der Griffe

- Stecken Sie die Schrauben (S2) von innen durch die seitlichen Bohrungen der Feuerschale.
- Legen Sie die Gegenmuttern (S3) an die Griffe und schrauben Sie die Schrauben (S2) dagegen, bis sie fest sind.

Schritt 3: Aufstellung

Stellen Sie die Feuerschale auf eine ebene und feste Fläche.







Hersteller: CHAL-TEC Vertriebs- + Handels GmbH, Wallstraße 16, 10179 Berlin, Deutschland



Dear Customer,

Congratulations on purchasing this Klarstein equipment. Please read this manual carefully and take care of the following hints on installation and use to avoid technical damages. Any failure caused by ignoring the mentioned items and cautions mentioned in the operation and installation instructions are not covered by our warranty and any liability.

Security Instructions

- The fire pit is for igniting a fire or embers.
- · Keep children and pets away from the fire.
- Do not place the fire pit near inflammable objects.
- Only adults are allowed to lit a fire.
- Take care that your clothing does not catch fire.
- · Do not leave the fire unattended.
- At the end extinguish the embers completely.

Scope of supply

- 1 fire pit bowl
- 3 bowl legs
- · 2 handles

- 6 hexagonal nuts
- 4 screws
- 4 washers

A	3	
D	1	
G	2	
S 1	6	©
S2	4	
\$3	4	®
S4	6	0



Installation

Required tools

- Wrench
- Screwdriver

Step 1:Fastening the bowl legs

- 1. Place a bowl leg with its two threads through the holes in the bowl.
- 2. Place two wahers (S4) on the respective threads from above.
- 3. Fasten a hexagonal nut (S1) on the respective thread.
- 4. Repeat the steps 1-3 for each bowl leg.

Step 2: Fastening the handles

- Insert the screws (S2) from the inside through the screw holes at the sides of the fire pit.
- Hold the counter nuts (S3) to the handles und fasten the screws (S2) against it until fixed.

\$3 \$2 ¢

Step 3: Setup

Set up the fire pit on a level and solid surface.



Producer: CHAL-TEC Vertriebs- + Handels GmbH, Wallstraße 16, 10179 Berlin, Germany