




blumfeldt

Balkon-Markise







10030627

Sehr geehrter Kunde,

wir gratulieren Ihnen zum Erwerb Ihres Gerätes. Lesen Sie die folgenden Hinweise sorgfältig durch und befolgen Sie diese, um möglichen Schäden vorzubeugen. Für Schäden, die durch Missachtung der Hinweise und unsachgemäßen Gebrauch entstehen, übernehmen wir keine Haftung.


Einzelteile

Beschreibung	Bild	Menge
A - markise und Roller		1
B - Klammer		1
C1 - Aufhängering		2
C2 - Haken		2
D - Plastikdübel		4
		6
		4
E - Sechskant-Blechschaube		6
		4
F - Kreuzschlitz-Blechschaube		


Beschreibung	Bild	Menge
G - Unterlegscheiben		6
		4
H - Sechskantschraube		4
I - Haken für Bänder		2
J - Bänder		2
K - Basis		3
L - Sechskantschlüssel (5 mm / 3 mm / 2.5 mm)		1
		1
		1

Befestigungs-Schemata


1. Fixierung der Markise am Boden




2. Fixierung der Markise mit Bändern am Handlauf



3. Fixierung der Markise an einem Balken




4. Fixierung der Markise an der Wand




Zusammenbau

Benötigte Werkzeuge




Zusammenbau


1. Bringen Sie die Klammer (B) an:



2. Bringen Sie den Aufhänger (C1) an:




3. Montierter Haken (sie benötigen Teil C2)




Nutzungsmöglichkeiten


1. Frei hängend




2. Seitlich an der Wand



3. Seitlich an der Wand



4. An einem Deckenbalken hängend




Hinweise zu Anbringung und Pflege

Schieben Sie den Roller (A) in die Klammer (B) und befestigen Sie die Klammer mit den 4 Sechskantschrauben (H), benutzen Sie dafür den 5 mm Sechskantschlüssel.

So balancieren Sie den Roller aus: Bringen Sie den Roller ins Lot und ziehen Sie dann die Schrauben fest. Falls der Roller etwas weiter herunter muss, lösen Sie die oberen Schrauben bis er im Lot ist.

Pflege: Wenn Sie die Markise länger nicht benutzen, lösen Sie sie und rollen Sie sie auf.








Hersteller




Chal-Tec GmbH, Wallstraße 16, 10179 Berlin, Deutschland.

Dear Customer,

Congratulations on purchasing this equipment. Please read this manual carefully and take care of the following hints to avoid damages. Any failure caused by ignoring the mentioned items and cautions mentioned in the instruction manual are not covered by our warranty and any liability.


Part List

Description	Picture	Quantity
A - Roller blind		1
B - Bracket		1
C1 - Hanging ring		2
C2 - Hook		2
D - Plastic expansion pipe		4
		6
		4
E - Hexagon tapping screw		6
		4
F - Cross head tapping screw		


Description	Picture	Quantity
G - Washers		6
		4
H - Inner hexagon cap screw		4
I - Magic strip hook		2
J - Magic strips		2
K - Base		3
L - Hexagon tapping screw (5 mm / 3 mm / 2.5 mm)		1
		1
		1

Schematic


1. The blind is fixed on the ground




2. The blind is fixed by magic straps on handrail



3. The blind is fixed on the beam




4. The blind is fixed on the wall




Assembly

Assembly tools




Assembly


1. Wall bracket mounted (need B, E in parts list):



2. Hanging ring mounted
(need F, C, D in the parts list):




3. Hook mounted (need C2 in the parts list)




Ways for usage


1. Used in horizontal




2. Used beside the wall



3. Used beside the wall




4. Used under the beam.



Hints on Installation and Care

Insert the roller (A) to the bracket (B), then tighten the four hexagonal bolts (H) with the 5 mm hexagonal wrench.

Adjusting the balance: keep the roller on correct level, then tighten the screws. If need the roller down, loose the upper screws till the roller is in the correct level.



Care: If no use for a long time, please retract the fabric into cassette.

Producer

Chal-Tec GmbH, Wallstraße 16, 10179 Berlin, Germany.