



Finish Care and Cleaning Instructions

Thank you for purchasing a fine decorative product from Brasstech®. GINGER® bathroom accessories are of the finest quality and will provide years of worry-free use with proper care and maintenance.

General Cleaning and Maintenance Instructions

- Always wipe your fixture down with a soft cloth after each use to prevent mineral build-up and water-spotting. Should spotting occur, remove water spots with warm water and a soft, damp cloth.
- Do not use abrasive cleaners, ammoniated products, rubbing alcohol, detergents, astringents, bleach based cleaners, aggressive chemicals, abrasive cleaning pads, or harsh polishes on the fixture. Use of such products may void the warranty.
- Do not allow soap scum or toothpaste to build up on the product. These will gradually wear away the protective coating and may diminish the beauty and durability of the finish.
- Brass ProTech (part# 98000) is exclusively made to clean, polish, and protect GINGER® products. Simply apply Brass ProTech with a soft cloth and let dry. Remove the polish by gently rubbing with a soft dry cloth to a high luster.

In addition to the guidelines noted above, please adhere to the following finish specific recommendations.

PVD Finishes (Polished Nickel – PN, Polished Brass – PB)

The PVD, or Physical Vapor Deposition, process creates the most durable finish available on the market today. Although these finishes are stain and tarnish resistant, never use bleach or any abrasive cleaner, cloth, or pad to clean the product. More specifically, avoid any and all cleaning products designed to remove tarnish or rust or any cleaning agent that contains hydrochloric, hydrofluoric, and/or phosphoric acid or caustic agents. Periodic cleaning can be done by applying Brass ProTech (98000) with a soft clean cloth to gently remove surface spots.

Clear Protective Coated Finishes (Hand Relieved Oil Rubbed Bronze-ORB, Satin Nickel - SN)

Even though these finishes are equipped with a clear protective coating they are susceptible to damage. If the topical clear coat is scratched or chipped the base material will be exposed and may oxidize. Use of abrasive cleaners or pads may remove the protective coating and damage the finish. Periodic cleaning can be done by applying Brass ProTech (98000) with a soft clean cloth to gently remove surface spots.

Powder Coat Finishes (Oil Rubbed Bronze-10B)

Powder coated color finishes **DO NOT HAVE A PROTECTIVE COATING** so they are susceptible to surface damage. If not properly cared for these products can be scratched, scuffed, or chipped. If the exterior color coating is damaged or compromised the underlying base material may tarnish and/or corrode. Use of abrasive cleaners or pads can remove or dull the color coating and damage the finish. Periodically clean the fixture with mild liquid soap or by applying Brass ProTech (98000) with a soft clean cloth to gently remove surface spots.