KHOR LENS REMOVAL



place thumbs on frame bridge & index fingers on inner lens edge



firmly push thumbs downward while pulling the lens edges apart



the lenses will "pop" allowing for easy removal of lens









KHOR LENS INSTALLATION

01 place outside lens edge in temple frame groove







once the lens is properly aligned in the track, firmly press into place



