

■ Order by Part Number

Spacer, Gasket, and
Mounting Stud
(For use with top mounted
sink lip heights up to
approximately 13/16 in.)

181149

Soap Vandal Sheathing
(Soap Tube not included)

182419

Mounting Hardware

182423

Installation Tool

118305

D-Cell Battery Box
(Batteries not included)

182421

AC Conversion Kit

AC Transformer
(up to 8 devices)

104630

Faucet AC Connector
(1 per device)

182538

M•POWER® Modern Style Electronic Soap Dispenser

MODEL
8560

FINISH
Chrome

Soap Tube, O-ring,
Spout Barb, & Soap Net
(Tube Sheathing not included)
(Nylon Washer is for use on
models made before Jan. 1, 2017)

182417

Mounting Bracket,
Vandal Shield &
Mounting Hardware
(Key included)

182416

Soap Dispenser –
Sensor, Bracket, & Screw
(Only for use with
Soap Dispenser)

182422

Electronics Box

182415

Non-drip Foam Soap Pump

182413

1500mL Soap Bottle

182414

■ Order by Part Number

M•POWER®	
Modern Style	
Electronic Soap Dispenser	
MODEL	FINISH
8560	Chrome

Spacer, Gasket, and
Mounting Stud
(For use with top mountned
sink lip heights up to
approximately 13/16 in.)

181149

Soap Vandal Sheathing
(Soap Tube not included)

182419

Mounting Hardware

182423

Installation Tool

118305

D-Cell Battery Box
(Batteries not included)

182421

Soap Net

182418

Wire Vandal Sheathing

182420

Soap Tube, O-ring,
Spout Barb, & Soap Net
(Tube Sheathing not included)

182417

Mounting Bracket,
Vandal Shield &
Mounting Hardware
(Key included)

182416

Soap Dispenser –
Sensor, Bracket, & Screw
(Only for use with
Soap Dispenser)

182422

Electronics Box

182415

Non-drip Foam Soap Pump

182413

1500mL Soap Bottle

182414