




External outfitting NR981-OD·NC1991-OD




External outfitting NR981-SV



External outfitting NR981-DVC



External outfitting NC1991-DVC




External outfitting 1 NR981(-OD.-SV.-DVC)·NC1991(-OD.-DVC)

Part Nos.	Part Names	Order Nos.	Q'ty/unit
001	NR981-OD Front SET-AS NC1991-OD Front SET-AS NR981-SV Front SET-AS NR981-DVC Front SET-AS NC1991-DVC Front SET-AS	SKH7198 SKH7199 SKH7222 SKH7209 SKH7210	1<NR981-OD> 1<NC1991-OD> 1<NR981-SV> 1<NR981-DVC> 1<NC1991-DVC>
002	Front packing 1 EAA	EAL002	2<OD · SV>
003	Front packing L AAP	AAPL017	2<OD · SV>
004	Mounting plate for current leakage safety device ESW	ESWA032	1
009	Lightning arrester127 ERD	ERD011	1
011	Connection diagram label ESW	ESWK001	1
012	Caution label ENG ELV	ELVK003	1
013	Caution label FRE ESW	ESWK006	1
014	Rating plate 2 OD (W) ELV	ELVK009	1<OD>
015	Rating plate 2 F ESW	ESWK004	1<SV>
022	Rating plate2 DW(FF) ELV	ELVK010	1<DVC>
025	Energy star mark ENJ	ENJ001	1
027	Cord bushing SR-SP-4	SAE6198	1<NR981-OD> 1<NC1991-OD> 1<NR981-SV> 1<NR981-DVC> 1<NC1991-DVC>
028	Air thermostat BWC	BWCH003	1
029	Parts list sheet set ESW-A Junction box cover (SUS) ENJ-A	ESWK082 ENJA025	1<NR981-OD> 1<NC1991-OD> 1<NR981-SV> 1<NR981-DVC> 1<NC1991-DVC>
035	Junction box cover packing ENW	ENWL005	1<NC1991-OD> 1<NC1991-DVC> 1<NR981-OD> 1<NR981-SV> 1<NR981-DVC>
036	External connection terminal block cover DNS	DNSA025	1<NC1991-DVC> 1<NR981-OD> 1<NC1991-OD> 1<NR981-SV> 1<NR981-DVC>
037	Remote control connection cautions label ENJ	DNSA026	1<NR981-OD> 1<NC1991-OD> 1<NR981-SV> 1<NR981-DVC> 1<NC1991-DVC>
040	Case set WX-W ENJ Case set WZ-W EVF Case SET F ESW Case set WX-FFA ESW Case set WZ-FFA EVF	ESWA001 EVFA101 ESWA011 ESWA021 EVFA121	1<NR981-OD> 1<NC1991-OD> 1<NR981-SV> 1<NR981-DVC> 1<NC1991-DVC>
041	Grommet CXP	CXPA026	1<NR981-OD> 1<NR981-DVC> 1<NC1991-DVC> 2<NR981-SV> 1<NR981-OD>
043	Grommet CXP Conduit 92-120V ENJ	CXPA026 ENJ020	1<NR981-OD> 1<NR981-DVC> 1<NC1991-DVC> 1<NR981-OD>
044	Fan Intake packing ERD	ERDL001	1<DVC>
045	Duct packing ERD	ERDL003	1<DVC>
046	Case top cover FFA ELV	ELVA099	1<DVC>
047	Mounting plate for remote controller ELV	ELVA100	1<NR981-DVC>
048	Remote controller (RC-7651MUSA) QXU	QXU015	1<NR981-DVC>
049	Nylon clamp HP-4N (NK-4N)	7287909	1<NR981-SV> 1<NR981-DVC> 1<NR981-OD>
050	Power supply cord ERD	ERDJ013	1<NR981-DVC> 1<NR981-OD>
051	Intake air filter DTG	DTGA015	1<NR981-SV>
052	Filter packing 1 DTG	DTGL012	2<NR981-SV>
053	Filter packing 2 DTG	DTGL013	2<NR981-SV>
054	Case top cover 2 EDL	EDLA005	1<NR981-SV>

External outfitting 2 NR981(-OD.-SV.-DVC)·NC1991(-OD.-DVC)

Part Nos.	Part Names	Order Nos.	Q'ty/unit
055	Exhaust cylinder packing EDL	EDLL002	1<NR981-SV>
056	Case top cover ELV	ELVA006	1<NR981-SV>
071	Cross recessed round-head collar P TIGHT screw 4X12 S410		<NR981-OD> <NC1991-OD> <NR981-SV> <NC1991-DVC>
072	Cross recessed round-head collar type3 EVERTIGHT tapping screw 4X12 S410		<NR981-OD> <NC1991-OD> <NR981-SV> <NC1991-DVC>
074	Cross recessed truss type3 EVERTIGHT tapping screw with PW 4X12 S410		<NR981-OD> <NC1991-OD> <NR981-SV> <NC1991-DVC>
076	Cross recessed blind machine screw M3.5X6 S430		<NR981-OD> <NC1991-OD> <NR981-SV> <NC1991-DVC>
077	Cross recessed round-head collar N-tapping screw 4X8 S410		<NR981-OD> <NC1991-OD> <NR981-SV> <NC1991-DVC>
079	Cross recessed round-head collar N-tapping screw 4X12 S410		<NR981-OD> <NC1991-OD> <NR981-SV> <NC1991-DVC>
080	Cross recessed truss machine screw M4X8 S430		<NR981-OD> <NC1991-OD> <NR981-SV> <NC1991-DVC>
081	Cross recessed truss N-tapping screw with PW 4X12 S410		<NR981-OD> <NC1991-OD> <NR981-SV> <NC1991-DVC>
082	Cross recessed round-head collar type3 EVERTIGHT tapping screw 4X20 SWRM8 Trivalent chromate		<NR981-DVC> <NR981-SV>
083	Cross & straight recessed truss type3 S TIGHT tapping screw 4X10 S410 Pre-coating		<NR981-DVC> <NR981-SV>
084	Cross recessed truss machine long dog point screw with PW (TORX) M4X12 S430	SAE6419	1<NR981-SV>


Combustion unit and gas route NR981(-OD.-SV.-DVC)·NC1991(-OD.-DVC)



Combustion unit and gas route NR981(-OD.-SV.-DVC)·NC1991(-OD.-DVC)


Part Nos.	Part Names	Order Nos.	Q'ty/unit
100	Combustion tube set ETP SET-V	SKH7184	1<OD · SV>
101	Combustion tube set FFA ESW SET-V	SKH7211	1<DVC>
102	Suction air joint packing ESW	ESWL001	1
103	Ignition plug set ESS SET-V	SKG7311	1
105	Mounting plate for plug SET ESW	ESWC011	1
106	Plug packing Q EHK	EHKL001	1
108	Gas pipe ETP	ETPE011	1
110	Main damper 17-13 EFW	EFWC033	1<LP>
111	Main damper 17-14 EFW	EFWC034	1<NG>
112	Fan motor 100 EJA(ENG) SET-AS	SKC7470	1<OD>
113	Fan motor 110 ESW SET-AS	SKC7683	1<SV>
114	Manifold joint packing top ERD	SKH7214	1<DVC>
115	Manifold joint packing bottom ERD	ERDL007	1
117	Bell-mouth φ44 CRU	ERDL009	1
126	Igniter ERD	CHUC045	1<OD · SV>
127	Mounting plate for igniter DTJ	ETFF031	1<DVC>
128	High-voltage cord 470	ERD012	1
132	Gas mech. manifold L1SES SET-AS	DTJA015	1
133	Gas mech. manifold L2AES SET-AS	SAC1229	1
134	Gas mech. manifold L1SES SET-AS	SKH7203	1<OD LP · SV LP>
135	Gas mech. manifold L2AES SET-AS	SKH7187	1<OD NG · SV NG>
136	Gas mech. manifold L1SES SET-AS	SKH7215	1<DVC LP>
137	Gas mech. manifold L2SES SET-AS	SKH7216	1<DVC NG>
138	O-ring JASO 2030 type 1	SA6044	5
139	Quick fastener25.4	6340601	1
140	O-ring P25.5	SAB1512	2
141	Gas fitting 20A SET ELW	ELWE021	1
142	Solenoid S16ERCJASO2030SETV	SKG7181	1
143	Solenoid S06 ERC SET-V	SKG7316	3
144	Conduit R10 ESW	ESWJ015	1
145	Feedback pipe S EHK	EHKA048	2<DVC>
146	Silicone tube ID6X12X650 BVH	BVHF007	1<DVC>
148	O-ring P4	2100908	1<DVC>

Hot-water feed route NR981(-OD.-SV.-DVC)•NC1991(-OD.-DVC




Part Nos.	Part Names	Order Nos.	Q'ty/unit
400	Heat exchanger & Exhaust box W SET-AS OPK	SKH7204	1<DD>
	Heat exchanger & Exhaust box W SET-AS OPK	SKH7206	1<SV>
	Heat exchanger & Exhaust box FFASET-ASOPK	SKH7189	1<DVC>
401	Thermal fuse F ERG label ETP SET-V	ERD4003	2
404	Freeze preventive heater 3 ERD	SKH7192	1
	Freeze preventive heater Q ETP fastener ERDSET-V	ELV4002	1
408	Remaining flame safety device 94 ELV	ERDD011	1
410	Water flow sensor set ERD	ETFD010	1
411	Water flow servo set 1 ETF	ETFD011	1
412	Water flow servo set 2 ETF		
413	Hot-water outlet fitting 20A EHU	ELV4004	1<NPS81>
414	Hot-water outlet fitting 20A SET EVF	ELVFD003	1<NC1991>
	Water inlet fitting 20A SET EJM	EJMD002	1
415	Water inlet thermistor-300 BWC	BWCD096	1
416	Drain cock CRU	CRUD003	1<NPS81>
417	Waterproof cover EBT	EBTD023	2
418	Chlorinated water-resistant O-ring P4	1323708	3
419	Thermistor holding plate ALS	ALS0088	2
420	Water outlet magnetic sensor BWC	BWCD090	1
421	Water inlet thermistor-300 BWC	BWCD097	1
424	Heat exchanger thermistor-300 BWC	BWCD098	1
426	Water filter cover DTJ	DTJD006	1
427	Water filter (SUS) EGB	EGBD003	1
428	QMF safety valve A(S)	SAAB211	1
429	Conduit R86 JBG	JBGJ024	1
430	Hot-water resistant O-ring P9	SAD6635	1<NPS81>
431	Hot-water resistant O-ring P9	SAD6635	2<NC1991>
432	Hot-water resistant O-ring P3	SAD6633	1<NPS81>
435	Quick fastener 16A	6340300	4
437	Sensor fastener CRU	CRUD055	1
438	Thermal fuse fastener EGL	EGL4002	4
439	Heater fastener SET ERD	ERD4001	2
440	Quick fastener 16-25	SAD6593	2
441	Chlorinated water-resistant O-ring P16	3223302	8
442	Freeze preventive heater 2 ERD	ERDH002	2<DD>
	Freeze preventive heater 2 ERD	ERDH002	1
444	Heater fastener L AMM	AMM001	1
446	Conduit 86 ETF	ETFJ033	1
447	Harness clip 16	SAB2775	1
448	Heater fastener LL CPL	CLPL002	2<SV DVC>
481	Front top packing CZR	CZRL001	1<DD>
484	Bypass pipe ESW	ESWD001	1
490	Quick fastener 22-2 ELV	ELVD011	1
492	Safety valve SET EGG	EGGD029	1<NC1991>
493	Intake pipe packing ELV	ELVD019	1<DVC>
494	Concentric pipe D FFA ELV	ELVFD90	1<DVC>
495	Drain pipe cover D FFA ELV	ELVFD97	1<DVC>
496	Pipe seal D FFA ELV	ELVFD96	1<DVC>
497	O-ring (P80) D FFA ELV	ELVFD98	1<DVC>
531	Cross recessed round-head P TIGHT screw 4X10 S305		
532	Cross & straight recessed round-head S TIGHT tapping screw 4X6 S410		
534	Cross recessed round-head P TIGHT screw 4X10 S410		
536	Cross recessed round-head machine screw M4X8 S430 Trivalent Chromate (Black)		

Electronic control unit, Remote controller and Attached set
NR981(-OD.-SV.-DVC)•NC1991(-OD.-DVC)



For NR981-OD • NR981-SV
RC-7651M-ENG



For NR981-OD
NC1991-OD
NR981-SV
NC1991-DVC

For NR981-SV
NC1991-DVC

Special part	Special part no.
Owner's guide	888
Installation manual	889

※ To request a French version of the Owner's guide or Installation manual, contact Noritz America.