ROHL KITCHEN ACCESSORIES COLLECTION



Traditional Soap/ Lotion Dispenser

LS950CAPC

ROHL KITCHEN ACCESSORIES COLLECTION





or a kitchen that is exceptionally luxurious and functional, ROHL offers a complete selection of accessories. All complement ROHL's exclusive collections of faucets and fixtures to dramatically accent a wide range of interior design themes. The filtered water faucets and soap dispensers in particular complement ROHL's Country, Perrin & Rowe®, and Modern collections.

Each accessory is available in the same finishes as ROHL's exclusive collections, allowing you to achieve authentic luxury down to every last detail.

Featured on cover:

Faucet with Handspray - Perrin & Rowe® U.4846LS-STN Undermount Stainless Steel Sink - RSS3018SS Wire Sink Grid (not shown) - WSGRSS3018SS Soap/Lotion Dispenser - LS450LSTN
Filter Faucet - Perrin & Rowe® U.KIT1601L-STN
Air Switch and Control Box - AS450STN Disposal Flange (not shown) -743STN Disposal Stopper (not shown) -744STN





A1635XMIB A1635LM - Metal Lever Handle A1635LP - Porcelain Lever Handle A1635X - Five Spoke Handle





Country Soap/Lotion

Dispenser


LS650CAPC

LS450LSTN

Manual Basket Strainer

AG700STN

with Large Pull Knob



All ROHL fireclay kitchen sinks have corresponding wire sink grids:

- Wire Sink Grid WSG6327SM, For use in 6317, 6327, 6339 and 6337 small bowl sinks
- Wire Sink Grid WSG6327LG, For use in 6317, 6327, 6339 and 6337 large bowl sinks
- . Wire Sink Grid WSG2418, For use in RC2418 sink
- Wire Sink Grid WSG1718, For use in RC1718 sink
- Wire Sink Grid WSG2416, For use in RC2416 sink
- Wire Sink Grid WSG6347, For use in 6347 sink
- Wire Sink Grid WSG3018, For use in RC3018 sink
- Wire Sink Grid WSG3223, For use in RC3223 sink
- Wire Sink Grid WSG3016, For use in RC3016 sink
- Wire Sink Grid WSG3516, For use in RC3516 sink
- Wire Sink Grid WSG3616, For use in RC3616 sink
- Wire Sink Grid WSG1318, For use in RC1318 sink
- Wire Sink Grid WSG3017, For use in RC301 sink
- Wire Sink Grid WSG1515, For use in RC1515 sink
- THE SHIR SHE WOSTOTO, FOR USE HEROTOTO SH
- Wire Sink Grid WSG6307, For use in 6307 sink
- Wire Sink Grid WSG3618, For use in RC3618 sink
- Wire Sink Grid WSG3021, For use in RC3021 sink
- Wire Sink Grid WSG2321, For use in RC2321 sink



- A Rinsing Basket RB6327, For use in 6317, 6327, 6339 and 6337 Sinks
- B Plate Rack PR6327, For use in 6317, 6327, 6339 and 6337 Sinks
- C Cutting Board CB6327, For use in 6317 and 6327 Sinks
- D Extended Flange ISE10082, For I.S.E. Disposals
- E Disposal Stopper/Escutcheon 744/743, For I.S.E. Disposals
- F Manual Strainer Basket without Pop-Up 733, Polished Chrome only
- G Manual Strainer Basket without Pop-Up 738, Stainless Copper
- H Strainer Basket with Remote Pop-Up 737, Includes Polished Chrome Basket
- 1 Strainer Basket with Remote Pop-Up 739, Includes White Basket
- J Air Switch Disposal Button and Control Box AS450
- K Sink Hole Cover SHC-1
- L Luxury Air Gap AG600
- M 10" Coverplate COP10; 6" Coverplate available COP6
- N Undermount Sink Kit QN25UM 25" QN36UM 36"

