

What The Lifetime Protection Plan Covers


Protection	Coverage
Fuel with O2 Sensor Protection	Fuel injectors, intake valves and O2 sensors
GDI Protection	Intake valves (Port fuel injected, Sequential fuel injected, GDI or carbureted engines)
Diesel Fuel Protection	Covers fuel injectors.
Engine Protection	Pistons, rings, cam shafts, and bearings, turbo bearings, lifters, oil pumps, wrist pins, bushings, push rods, crankshaft and bearings, rods and rod bearings, timing chains, timing gears or sprockets, intake valves and guides, cylinder liners or bores, rocker arms and pivots and distributor drives.
Power Steering Protection	Lubricated parts contained within the power steering gearbox or rack and power steering pump.
Cooling System Protection	Heater core, water pump, freeze plugs, and radiator.
Automatic Transmission Protection	Covers any lubricated parts contained within the automatic transmission housing or case except seals and gaskets.
Transfer Case / Manual Transmission Protection	Covers the lubricated parts contained within the Transfer Case / Manual Transmission housing or case except seals and gaskets.
Differential Protection	Covers lubricated parts contained within the differential housing or case.
Brake Fluid Protection	Covers the pump, valves, master cylinder, calipers, and metalized hoses.

Platinum Plus Plan

- Initial service occurs between 0-50,000 miles / 0-80,000 km
- Coverage is effective immediately upon completing the initial service
- \$4,000 USD / \$5,000 CDN
- \$5,000 USD / \$6,000 CDN for qualifying engine oil service

Gold Plan

- Initial service occurs between 50,001-100,000 miles / 80,001-160,000 km
- Coverage shall commence 3-months or 500 miles (800 km) following the initial service (whichever occurs first)
- \$2,000 USD / \$2,500 CDN
- \$2,500 USD / \$3,000 CDN for qualifying engine oil service.



TerraClean Lifetime Protection Plan

Your vehicle is likely the second largest investment you will ever make, and you depend on it to be there when you need it. It only makes sense to maintain it properly. Maintaining your vehicle costs less than repairing it. In fact, if you maintain it properly, you may avoid the possibility of paying for costly repairs altogether.

TerraClean is a leader in automotive maintenance services. We supply service facilities with the chemicals and equipment that your technician uses to service your vehicle. When a TerraClean service is performed on your vehicle, you may be eligible for protection on the related components for the lifetime of the vehicle.

Coverage and Service Intervals

Your vehicle may be eligible for coverage up to \$4,000 depending on the mileage of the vehicle when the first TerraClean Service is performed. Your coverage will continue as long as you continue to service your vehicle with the TerraClean System before the next mileage interval. Please see Lifetime Protection Plan for Details.

Service	Protection	Service Interval		
		Every Oil Change Interval ***	Every 15,000 miles 25,000km	Every 30,000 miles 50,000km
Fuel	Fuel Protection with O2 Sensor Protection		**	•
	GDI Protection		**	•
	Diesel Fuel Protection	•		
Engine	Engine Protection	•		
Power Steering	Power Steering Protection			•
Cooling	Cooling System Protection			•
Power Train	Automatic Transmission Protection / CVT Protection			•
	Transfer Case / Manual Transmission Protection			•
	Differential Protection			•
Brake Fluid	Brake Fluid Protection			•

** In order to qualify for intake valve coverage on GDI engines. A GDI kit (201457 or 201458) must be used.

*** According to the OEM oil change mileage requirements to a maximum interval of one year.

