
















CROSLEY

FURNITURE



Record Storage Cube Bookcase CF1325



PART LIST

A2 	B2 	C2 	D2 	E2 
Top Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Bottom Panel 1 PC	Back Panel 2 PCS
F2 	G2 	H2 	I2 	J2 
Partition Panel 1 PC	Back Rail 1 PC	Drawer Front Panel 1 PC	Drawer Left Panel 1 PC	Drawer Right Panel 1 PC
K2 	L2 	M2 	N2 	O2 
Drawer Back Panel 1 PC	Drawer Bottom Panel 1 PC	Upper Fixed Shelf Panel 1 PC	Lower Fixed Shelf Panel 1 PC	Back Slat 1 PC
P 	Q 			
Leg 4 PCS	Center Leg 1 PC			

HARDWARE LIST

<p>#1</p>  <p>Ø3*15mm</p> <p>Short Screw</p> <p>8 PCS (Extra 1)</p>	<p>#2</p>  <p>Ø3*30mm</p> <p>Long Screw</p> <p>4 PCS</p>	<p>#3</p>  <p>Ø7*38mm</p> <p>Screw</p> <p>10 PCS (Extra 2)</p>	<p>#4</p>  <p>Ø5/32"*22mm</p> <p>Round Head Bolt</p> <p>2 PCS</p>	<p>#5</p>  <p>Ø1/4"*15mm</p> <p>Bolt</p> <p>2 PCS</p>
<p>#6</p>  <p>Ø1/4"*30mm</p> <p>Long Bolt</p> <p>16 PCS (Extra 2)</p>	<p>#7</p>  <p>Ø8*30mm</p> <p>Wood Dowel</p> <p>26 PCS (Extra 2)</p>	<p>#8</p>  <p>350*35*11mm</p> <p>Handle</p> <p>1 PC</p>	<p>#9</p>  <p>4mm</p> <p>Allen Wrench</p> <p>1 PC</p>	<p>#10</p>  <p>Back Bracket</p> <p>8 PCS</p>
<p>#11</p>  <p>Safety Strap Kit</p> <p>1 SET</p>				

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.


Please do not use tools to assemble this unit unless specifically indicated.




Reference the images above any time the instructions state "lock the hardware" or "insert hardware and pull down to lock".

Be sure to check all hardware is locked when complete.


Step 1. Insert drawer left panel (part I2) and drawer right panel (part J2) into drawer front panel (part H2) pull down to lock. Slide drawer bottom panel (part L2) into grooves of assembled unit (parts H2, I2 & J2). Attach drawer back panel (part K2) to assembled unit (parts I2, J2 & L2) using long screws (part #2) and phillips head screwdriver. Attach handle (part #8) to drawer front panel (part H2) using round head bolts (part #4) and phillips head screwdriver.



Step 2. Insert lower fixed shelf panel (part N2) to partition panel (part F2).




Step 3. Attach upper fixed shelf panel (part M2) to partition panel (part F2) using wood dowels (part #7), screws (part #3) and phillips head screwdriver.




#3  x 2

#7  x 2


Step 4. Attach panels (parts B2 & C2) and back rail (part G2) to panels (parts F2, M2 & N2) using wood dowels (part #7) and lock the hardware.




Step 5. Attach bottom panel (part D2) to assembled unit (parts B2, C2, F2 & G2) using wood dowels (part #7), screws (part #3) and phillips head screwdriver.




Step 6. Attach legs (parts P & Q) to bottom panel (part D2) using bolts (parts #5 & #6) and allen wrench (part #9).




Step 7. Carefully turn unit upright. Attach back slat (part O2) to back rail (part G2) using wood dowels (part #7).



Step 8. Insert back panels (part E2) into grooves of assembled unit (parts B2, C2, G2 & O2).




Step 9. Attach top panel (part A2) to assembled unit (parts B2, C2 & O2) using wood dowels (part #7) and lock the hardware.




Step 10. Slide assembled drawer into place.

Note: To release trigger disconnect levers push one side up and the other down.





Note: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

Step 11. Secure back brackets (part #10) at the corner of back panels (part E2) using short screws (part #1) and phillips head screwdriver.
Important: Safety strap kit (part #11) must be installed to prevent tipping, damage and /or injury.



- | | | |
|-----|---|-----|
| #1 |  | x 8 |
| #10 |  | x 8 |


#11	A	B	C	D	E
			 D8*3/4"	 D8*1-1/2"	
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Washer 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) through washer (B) and safety wall strap (E) and attach to top panel (part A2) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in top panel (part A2) where the safety wall strap (E) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) through washer (B) and safety wall strap (E) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING	
	<p>Children have died from furniture tipover. To reduce the risk of furniture tipover:</p> <ul style="list-style-type: none"> • ALWAYS install tipover restraint provided. • NEVER put a TV on this product. • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heaviest items in the lowest drawers. <p><i>This is a permanent label. Do not remove!</i></p>
	