






CROSLEY

FURNITURE






Dining Table CF2014



PART LIST


A	B	C	D
			
Table Top 1 PC	Support Bar 2 PCS	Leg 4 PCS	Table Leaf 1 PC

HARDWARE LIST

#1	#2	#3	#4	#5
				
M6 X 70mm	M6 X 40mm	M6	M6	M4
Long Bolt 8 PCS (Extra 1)	Bolt 4 PCS (Extra 1)	Spring Washer 12 PCS (Extra 1)	Flat Washer 12 PCS (Extra 1)	Allen Wrench 1 PC

ADDITIONAL TOOLS (Not Provided)


Note : It is not recommended to use power tools during assembly.







Phillips Head Screwdriver

Step 1. Lay table top (part A) upside down on a soft surface, such as carpet. Attach legs (part C) to table top (part A) using long bolts (part #1), spring washers (part #3), flat washers (part #4) and allen wrench (part #5).


Note : Please fully tighten all bolts.







#1		x8
#3		x8
#4		x8
#5		x1


Step 2. Attach support bars (part B) to table top (part A) using bolts (part #2), spring washers (part #3), flat washers (part #4) and wrench (part #5).

Note : Please fully tighten all bolts.




#2		x4
#3		x4
#4		x4
#5		x1

Step 3. Carefully turn unit upright. To insert table leaf (part D), unlock the clamp locks underneath table top (part A) and pull on opposite ends to separate.



Step 4. Place table leaf (part D) in position and push table top (part A) from both ends to close.

Note : Ensure clamp locks line up correctly when inserting table leaf (part D).



Step 5. Lock clamp locks underneath table top (part A) to secure.

