

PARTS AND HARDWARE

- Locking Casters x2
- Non-Locking Casters x2
- Caster Bolts x16
- Black Screws x12


INCLUDED TOOLS

- Hex Key

TOOLS NEEDED

- Phillips Screwdriver

THE WIZARD



ASSEMBLING THE CASTERS

To assemble the **Casters**, lay the unit down on its back (doors facing up) on a clean soft surface. The Casters should be assembled by simply lining up the holes on the base of the Caster with the plastic Sockets on the bottom of the unit. Use the **Hex Key** that is provided with the unit to tighten the **Bolts**.

NOTE: There are two **Locking** and two **Non-Locking Casters**. Install the two **Locking Casters** at the front of the unit for easier access while standing behind the unit.

SIDE FLIP UP SHELF

To properly assemble the **Side Shelf**, start by opening the **Support Arms** to the upright and secure position. Place the Shelf on top of the Arms and align the holes with the pre drilled holes underneath the Shelf. Use a **Screwdriver** or a **Drill** to secure the Shelf to the Arms.



Double check all Bolts and Screws to be tightened securely before use. Check all Bolts and Screws periodically. Failure to completely tighten the Bolts and Screws may result in tipping and possible injury!

Congratulations, your WIZARD A/V CART is now assembled and ready to be used!

Dear Customer, Thank you for your purchase. Although extreme care goes into manufacturing & packaging of this product, mistakes are possible. If you encounter any missing parts or difficulty in assembly, please contact our customer service Toll Free at 1-800-261-4112 or info@nationalpublicseating.com for courteous & immediate resolution to your problem.