

# **SALTRIVER APARTMENTS INTERCOM INSTRUCTIONS FOR: 21 & 31 Moreland Street & 5 Saltriver Place**



## **DOOR STATION**

- To dial an apartment from the entry, enter Apartment number then “#” key  
E.g. “101#”
- For 5 Saltriver Place / 31 Moreland Street, to use your entry token, swipe token over the card reader.
- For 21 Moreland Street, to use your entry token, swipe token over separate card reader below the door station.



## **APARTMENT MONITOR**

- To answer a call, press the green answer button on the touch screen which appears when the monitor is ringing.
- To unlock the door and release the lift click the unlock button on the touch screen (the lift will be released for 120 seconds).
- The previous physical lift release buttons are no longer operational.
- To hang-up or cancel a call press the red hang up button on the touch screen.