

A020300 and A020305 Air Sensing Thermostat - how to connect thermostat wiring.

To use this thermostat in a fridge or freezer connect the two thermostat wires to terminals P1 & 2

See the red arrows below. The thermostat wires can be connected either way round as they are not polarised.

